



## INDEX

1 TO 3 FARAD CAPS [CAR] . . . 18-30  
 1 UH TO 10 MH INDUCTORS . . . 02-13  
 1/4 HEX DRIVER . . . 14-03  
 1/4 HEX TIPS . . . 14-05  
 1/4 TO 10 WATT RESISTORS . . . 02-14  
 10V TO 6000V CAPACITORS . . . 02-03  
 12V  
 240V INVERTOR . . . 12-34, 18-32  
 BATTERY MONITOR . . . 11-21  
 AIR COMPRESSOR . . . 14-66, 18-51  
 CABLE . . . 13-08, 18-26  
 DC TO DC [CAR] . . . 12-32, 18-30  
 FLUORO INVERTOR . . . 12-34  
 IMPACT WRENCH . . . 18-51  
 POWER SUPPLY . . . 12-28  
 QUARTZ HALOGEN . . . 12-11  
 TV POWER BLOCK . . . 03-07  
 WARNING LAMPS . . . 18-25  
 WORK LIGHT . . . 18-51  
 13.8V POWER SUPPLY . . . 12-29  
 1.5V BATTERIES . . . 11-04  
 2.0 SPEAKERS FOR PC . . . 16-09  
 2.1 SPEAKER SYSTEM . . . 16-09, 17-45  
 2.4 GHZ AV SENDER . . . 20-30  
 2.4 GHZ WIRELESS CAMERA . . . 21-24  
 2.5 TO 3.5 HDD ADAPTOR . . . 16-43  
 3.5 INCH FLOPPY DISKS . . . 20-38  
 4.433 MHZ CRYSTALS . . . 02-17  
 5.1 CHANNEL SOUND CARD . . . 16-50  
 5.1 SPEAKERS . . . 06-09, 16-09  
 5.8 GHZ AV SENDER . . . 20-31  
 7.2V HOBBY BATTERIES . . . 11-20  
 100V LINE SPEAKER . . . 06-17  
 1400 PIECE SCREW SET . . . 14-69  
 240V AC MAINS  
 115V STEP DOWN POWER . . . 12-19  
 12V INVERTER . . . 12-34  
 CIRCUIT BREAKER . . . 12-16  
 CLEAN POWER BRAND . . . 12-04  
 CORDS [DIY] . . . 12-15  
 CORDS [EXTENSION] . . . 12-13  
 DOUBLE ADAPTOR . . . 12-11  
 ISOLATION TRANSFORMER . . . 12-21  
 LAMPS . . . 12-10  
 OVERSEAS ADAPTOR . . . 12-19  
 POWER BOARDS . . . 12-04  
 QUARTZ HALOGEN . . . 12-11  
 RCD POWER . . . 12-09  
 SURGE PROTECTOR . . . 12-04  
 TIMERS . . . 12-08  
 TRANSFORMERS . . . 12-20  
 TRAVELERS KITS . . . 12-19  
 UPS . . . 12-02  
 VARIAC [VARIABLE AC] . . . 12-21  
 24V [TRUCK BATTERY]  
 12V REDUCER . . . 12-33, 18-32  
 FLURO INVERTER . . . 12-34  
 300 OHM RIBBON CABLE . . . 13-06  
 50 OHM COAX CABLE . . . 13-07  
 5000 VOLT FUSES [MWO] . . . 10-13  
 6V LANTERN BATTERY . . . 11-04  
 75 OHM COAX CABLE . . . 13-06  
 COUPLER/SPLITTER . . . 09-02, 09-19  
 8 MM VIDEO  
 CASSETTE WINDER . . . 04-101  
 HEAD CLEANER . . . 04-100  
 TAPES BLANK CASSETTES . . . 20-34  
 9V BATTERY SNAP LEADS . . . 11-70  
 9V SMOKE ALARM BATTERY . . . 11-04

## A

AC POWER MAINS 240VAC  
 240V INVERTORS . . . 12-34  
 240V TO 115V . . . 12-19  
 APPLIANCE LEADS . . . 12-12  
 APPLIANCE TEST . . . 14-42  
 BREAKERS PANEL MOUNT . . . 12-16  
 CABLE . . . 12-15, 13-12  
 CABLE CEILING ROSE . . . 12-14  
 CABLE CLIPS . . . 12-18  
 CABLE GROMMETS . . . 12-15  
 CABLE SPLICES . . . 07-42  
 CABLE STRAIN RELIEF . . . 12-15, 13-15  
 CABLE TIES & DRESSING . . . 13-17  
 CORD SAFETY LOCK . . . 12-13  
 DOUBLE ADAPTOR . . . 12-11  
 ENERGY SAVE LAMPS . . . 12-10  
 EXTENSION CORDS . . . 12-13  
 FUSE HOLDERS . . . 02-25  
 HEAD [VCR] . . . 04-09  
 INPUT SOCKETS . . . 12-14  
 JUG ELEMENT . . . 12-11  
 JUNCTION BOX . . . 12-17  
 LAMP BATTEN HOLDER . . . 12-14  
 LAMPS . . . 12-10  
 LEADS IEC & ALLIANCES . . . 12-12  
 LEADS COMPUTER & UPS . . . 12-12  
 MAINS LAMP DIMMER . . . 12-16  
 MOUNTING BLOCKS . . . 12-17  
 PLUG MAINS 3 PIN . . . 12-14  
 POWER ADAPTORS DC . . . 12-22  
 POWER ADAPTORS TRAVEL . . . 12-19

POWER BOARDS . . . 12-04  
 POWER PACKS . . . 12-22  
 POWER POINT . . . 12-14, 12-16  
 POWER TIMER . . . 12-08  
 QUARTZ HALOGEN GLOBES . . . 12-11  
 SAFETY PLUG CHILD BLOCKER . . . 12-15  
 SAFETY SCREWDRIVER . . . 12-18  
 SAFETY SWITCH [RCD] . . . 12-09  
 SOCKET & RECEPTACLES . . . 12-14  
 SURGE PROTECTOR ONLY . . . 12-09  
 SWITCHPOT . . . 03-02  
 SWITCHES . . . 02-27, 12-16  
 TERMINAL STRIPS . . . 12-18  
 TRANSFORMER . . . 12-20  
 UPS . . . 12-02  
 VOLTAGE FINDER . . . 12-17  
 WALL PLATES . . . 12-16  
 MORE? . . . SEE AC SECTION 12  
 ACOUSTIC PADDING . . . 06-43  
 ACTIVE SPEAKERS PC . . . 06-09  
 ACTIVE SPEAKERS PA . . . 06-25  
 ADAPTOR PLUGS [REFERENCE] . . . 07-28  
 ADAPTORS  
 2.5 TO 3.5 HDD . . . 16-43  
 AC POWER . . . 12-19, 12-22  
 ANTENNA [MOBILE PHONE] . . . 17-19  
 AUDIO & VIDEO PLUGS . . . 07-30  
 BALUN [ANTENNA] . . . 07-31, 09-02  
 BNC . . . 07-32  
 CAR AERIAL . . . 07-40  
 CAR RADIO AUDIO . . . 18-35  
 CAR RADIO POWER . . . 07-41, 18-52  
 CB RADIO SSB MARINE . . . 07-25, 19-10  
 CD TO CASSETTE . . . 05-21  
 COMMUNICATION . . . 07-25, 19-10  
 COMPUTER . . . SEE COMPUTER  
 COMPUTER ATX EXTEND . . . 07-41  
 CRT TESTER . . . 14-40  
 D PLUGS [PC] . . . 16-108  
 DOUBLE ADAPTOR [AC] . . . 12-11  
 DVI TO HDMI & VGA . . . 08-05  
 DVI-D TO DFP20 . . . 08-05  
 F TYPE . . . 07-32  
 GAME CONSOLES . . . 15-02, 16-07  
 GAMEBOY . . . 15-16  
 HDMI . . . 08-06  
 KEYBOARD [COMPUTER] . . . 16-108  
 LUCENT . . . 07-37  
 MAINS TRAVEL . . . 12-19  
 MAINS POWER . . . 12-22  
 M1-DA . . . 08-06  
 MINI DVI . . . 08-06  
 MINI TV ANTENNA . . . 09-02  
 NINTENDO WII . . . 15-03  
 NULL MODEM . . . 16-107, 16-114  
 OVERSEAS [POWER AC] . . . 12-19  
 PL259 . . . 07-37  
 PLAYSTATION . . . 15-08, 15-10  
 PLAYSTATION PSP AV . . . 15-06  
 PLAYSTATION CAR POWER . . . 15-09  
 POWER PACKS [AC] . . . 12-22  
 RCA . . . 07-30, 08-21  
 RF [TV ANTENNA] . . . 07-31  
 RJ11/RJ45 KIT . . . 16-97  
 SCART . . . 07-31  
 SCART TO RCA & S-VIDEO . . . 08-10  
 S-VHS . . . 07-31  
 SCS1 . . . 16-110  
 SMA . . . 07-33  
 S-VIDEO . . . 08-21  
 TELEPHONE . . . 07-44  
 TNC . . . 07-35  
 TRAVEL . . . 12-19  
 TV . . . 07-31, 09-02  
 USB . . . 16-126  
 VHS-C TO VHS . . . 04-100  
 VIDEO . . . 07-30  
 XBOX . . . 15-14  
 ADHESIVE GLUE . . . 14-61  
 ADHESIVE TAPE . . . 14-58  
 ADJUSTABLE WRENCH . . . 14-17  
 ADSL  
 ACCESSORIES . . . 07-47, 16-97  
 MODEM & ROUTER . . . 16-89, 16-95  
 AERIAL . . . SEE ANTENNA  
 AEROSOL . . . 14-66  
 AIR COMPRESSOR [TYRE PUMP] . . . 18-51  
 AIR DUSTER CAN . . . 14-66  
 ALARMS . . . 21-28  
 ALKALINE BATTERY . . . 11-03  
 ALLEN KEY SCREWS . . . 14-69  
 ALLEN KEYS . . . 14-08  
 ALLIGATOR CLIP . . . 07-19, 14-51  
 ALLIGATOR CLIP LEADS . . . 14-50  
 ALTITUDE [AUDIO AMP] . . . 06-112  
 AMATEUR RADIO ACCESSORIES  
 [SEE COMMUNICATION] . . . 19-04  
 AMATEUR ANTENNA . . . 19-18  
 AMATEUR ANTENNA BASES . . . 19-14  
 AMPHENOL CABLES . . . 08-19  
 AMPHENOL CONNECTOR . . . 07-09  
 AMPLIFIED ANTENNA . . . 09-08  
 AMPLIFIED SPEAKER . . . 06-09, 06-25  
 AMPLIFIER  
 ANTENNA . . . 09-02, 09-15  
 ANTENNA MASTHEAD . . . 09-20  
 AUDIO [VALVE] . . . 06-112  
 MODULE [AUDIO] . . . 01-15, 06-37  
 PUBLIC ADDRESS . . . 06-22  
 SATELLITE . . . 09-04, 09-18

SPEAKER . . . 06-09, 06-25  
 SUBWOOFER . . . 06-37, 06-109  
 TV ANTENNA . . . 09-02, 09-15  
 TV DISTRIBUTION . . . 09-19  
 VIDEO . . . 09-17  
 ANALOGUE  
 AUDIO TO OPTIC CONVERT . . . 05-22  
 MULTIMETER . . . 14-48  
 TIMER [MANS] . . . 12-08  
 TV PATTERN GENERATOR . . . 14-39  
 VIDEO SYSTEM CONVERTER . . . 20-08  
 VIDEO MIXER . . . 16-76, 20-05  
 ANSWER MACHINE TAPES . . . 05-20  
 ANTENNA  
 ACCESSORIES . . . 09-02  
 ADAPTORS . . . 07-31, 17-19  
 ADAPTORS [COMMS] . . . 19-10  
 ADAPTOR [MOBILE PHONE] . . . 17-18  
 AMATEUR RADIO CB-SSB . . . 19-19  
 AMPLIFIED [INDOOR] . . . 09-08  
 AMPLIFIER . . . 09-02, 09-15, 09-19  
 AMPLIFIER [MASTHEAD] . . . 09-19  
 ATTENUATORS [COMMS] . . . 19-17  
 ATTENUATORS [RF] . . . 09-03-5  
 BASES [CAR COMMS] . . . 19-14  
 BASE SPRINGS . . . 19-15  
 BOAT [TV / FM] . . . 09-09  
 BOOSTER CAR AM/FM . . . 18-36  
 BOOSTER TV . . . 09-02, 09-15, 09-19  
 CABLE / COAX . . . 13-06, 19-13  
 CAR CROSS REF . . . 18-74  
 CAR GUTTER MOUNT . . . 18-73, 19-16  
 CAR [MOBILE PHONE] . . . 17-14, 17-22  
 CAR PLUG . . . 07-40  
 CAR RADIO . . . 18-59  
 CAR TV . . . 09-09  
 CARAVAN [TV / FM] . . . 09-09  
 CB . . . 18-69, 19-20  
 CELLULAR . . . 17-22  
 CORDLESS PHONE . . . 09-09  
 DISTRIBUTION PRO GME . . . 09-18  
 DIVERSITY [DUAL] . . . 18-68  
 DUMMY LOAD [COMMS] . . . 19-17  
 FIELD STRENGTH . . . 14-41  
 FM . . . 09-08  
 FM CONVERT JAPAN RADIO . . . 18-36  
 GPS [AUTO] . . . 18-68  
 GPS & GSM . . . 17-14, 19-02  
 GSM & NEXT-G . . . 18-70  
 GUTTER MOUNTS [CAR] . . . 19-16  
 HOLE COVER [CAR] . . . 19-15  
 INDOOR . . . 09-08  
 INPUT SOCKETS [TV] . . . 03-02  
 LEADS [NEXT-G / 3G] . . . 16-93  
 LEADS [TV] . . . 08-25  
 LIGHTNING ARRESTER . . . 12-04  
 LIGHTNING ARRESTER . . . 19-17  
 MAGNETIC BASS [COMMS] . . . 19-16  
 MARINE . . . 17-26, 19-20  
 MARINE AM/FM . . . 19-19  
 MASK BRACKETS [COMMS] . . . 19-17  
 MOBILE 27MHZ VHF . . . 18-69, 19-20  
 MOBILE 477MHZ UHF . . . 18-69, 19-21  
 MOBILE - EXTERNAL . . . 17-22  
 MOBILE - INTERNAL . . . 17-14  
 MOUNTING [AUTO] . . . 18-73  
 MOUNTS . . . 17-25, 19-14  
 NEXT-G / GSM . . . 16-94, 17-22  
 OUTDOOR ROTATOR . . . 09-15  
 PANASONIC PHONE . . . 09-09  
 PATCH LEADS [COMMS] . . . 19-12  
 PATCH LEADS [MOBILE] . . . 17-18  
 PLUG [TV ANTENNA] . . . 07-23  
 PLUG & SOCKET [COMMS] . . . 19-08  
 POWER INJECT / SUPPLY . . . 09-21  
 ROTATOR . . . 09-15  
 RUBBER DUCKY [PHONE] . . . 09-09  
 SCANNER . . . 19-18  
 SOCKETS [TV ANTENNA] . . . 07-23  
 SPIRAL [TV] . . . 09-08  
 SPLITTER [TV] . . . 09-02  
 SPRINGS [COMMS] . . . 19-15  
 SURGE PROTECTOR . . . 12-04  
 SWITCH . . . 09-02, 19-17  
 SWR & POWER METER . . . 19-17  
 TELEPHONE CORDLESS . . . 09-09  
 TELESCOPIC . . . 09-10  
 THROUGH GLASS . . . 17-14, 17-22  
 TV INDOOR . . . 09-08  
 TV INPUT SOCKETS . . . 03-02  
 VSWR & POWER METER . . . 19-17  
 WIFI [PC] . . . 16-90  
 WINDOW STRIP . . . 18-68  
 WIRELESS BROADBAND . . . 16-93  
 WIRELESS BROADBAND . . . 17-28  
 WIRELESS INTERNET . . . 16-95  
 WIRELESS NETWORK . . . 16-90  
 ANTISTATIC ESD  
 BAGS FOR COMPONENTS . . . 01-16  
 CLEANING LIQUID [SCREEN] . . . 16-79  
 EARTH PLUG [240VAC] . . . 14-57  
 GLOVES NITRILE & LATEX . . . 14-57  
 HEEL STRAP . . . 14-57  
 MAT FOR WORK DESK . . . 14-57  
 SERVICE KIT . . . 14-57  
 SPRAY CAN & SQUEEGEE . . . 14-67  
 WIPES . . . 14-62  
 WRIST BAND . . . 14-57  
 APPLE DATA CABLES [PC] . . . 16-112  
 APPLIANCE

LEAD [240V AC] . . . 12-12  
 TESTER . . . 10-12, 14-42  
 APPLICATORS & SWABS . . . 14-65  
 ARCHITRAVE SWITCH . . . 12-16  
 ARRESTER SURGE & SPIKE . . . 12-04  
 ATTACHE TOOL CASE . . . 14-19  
 ATTENUATOR  
 ANTENNA [F TYPE] . . . 07-32, 09-05  
 ANTENNA [PAL TYPE] . . . 09-03  
 COMMS RF . . . 19-17  
 SPEAKER [WALL] . . . 06-19  
 TV RF . . . 09-03, 09-05  
 AUDIO  
 ACCOUSTIC REFERENCE . . . 18-39  
 ADAPTOR . . . 07-30  
 AMPLIFIER . . . 01-15, 06-37, 06-112  
 ANALOG TO OPTICAL . . . 05-22, 08-03  
 AV SENDER . . . 20-30, 21-08  
 BELTS . . . 05-02  
 BLUETOOTH ACCESSORIES . . . 17-08  
 CABLE . . . 13-02  
 CAR . . . 18-02  
 CASSETTE TAPES . . . 20-35  
 CD ALIGNMENT DISKS . . . 05-19  
 CD BLANK DISKS . . . 05-20  
 CD TEST DISKS . . . 05-19, 14-56  
 CONNECTOR . . . 07-02, 07-30  
 CONTROL HEAD [VCR] . . . 04-09  
 CROSSOVER PARTS . . . 18-44  
 DAT TAPE . . . 05-20  
 DISTRIBUTION . . . 06-20, 20-28  
 HARNESS [CAR] . . . 18-52  
 HEAD CLEANER . . . 20-35  
 HEADS . . . 05-04  
 HEADS [VCR] . . . 04-09  
 IDLERS . . . 05-05  
 LEADS . . . 08-01  
 CONVERTERS . . . 20-10  
 MICROCASSETTES . . . 05-20, 20-35  
 MIXER . . . 05-22, 06-24  
 MODULATOR . . . 20-10  
 PINCH ROLLER . . . 05-05  
 PLUG . . . 07-02, 07-30  
 PRE-AMPLIFIER [PHONO] . . . 05-22  
 REFERENCES . . . 18-39  
 REMOTE CONTROLS . . . 20-15  
 REMOTE EXTENDER . . . 20-30  
 REMOTE REPEATER . . . 20-23  
 SWITCHES . . . 20-10  
 TAPE . . . 05-20, 20-35  
 VCR TOOLS . . . 04-99  
 VIDEO TAPES . . . 20-34  
 AUTOMOTIVE [SEE CAR]  
 AV  
 CABLE . . . 13-04  
 DISTRIBUTION . . . 09-17, 20-14, 20-28  
 EXTENDER . . . 20-24  
 GAME SELECTOR . . . 15-19  
 LEADS . . . 08-10  
 LEADS [HI QUALITY] . . . 08-12  
 LEADS [GAMEBOY] . . . 15-17  
 LEADS [NINTENDO WII] . . . 15-03  
 LEADS [PLAYSTATION] . . . 15-10  
 LEADS [PLAYSTATION PSP] . . . 15-06  
 LEADS [XBOX] . . . 15-14  
 MODULATOR . . . 09-13, 20-32  
 MODULATOR [GAME] . . . 15-18  
 MODULATOR [PSX] . . . 15-10  
 MODULATOR [XBOX] . . . 15-14  
 OVER CATS . . . 20-25  
 SENDER . . . 09-12  
 SPLITTERS . . . 20-14  
 SWITCH BOX . . . 15-19, 20-10  
 TO RF ADAPTOR . . . 09-13  
 WIRELESS SENDER . . . 20-30  
 AVIATION STYLE HEADSET . . . 06-08  
 AXIAL LAMPS . . . 02-21  
 B  
 BACK-SHELLS . . . 16-106  
 BACKUP BATTERIES . . . 11-07, 11-18  
 BAGS PLASTIC . . . 01-16  
 BALUN  
 LINE [RCA TO XLR] . . . 07-06  
 MASTHEAD . . . 09-03  
 TV . . . 09-02  
 BANANA PLUGS . . . 07-04  
 BAND SEPARATOR UHF-VHF . . . 09-02  
 BAND, TENSION [VCR] . . . 04-85, 04-97  
 BASE REFLEX PORT . . . 06-43  
 BASES [ANTENNA] . . . 19-14  
 BATTEN HOLDER LAMP . . . 12-14



BATTERY	11-02	AUDIO CASSETTE	05-20, 20-35	HEAVY DUTY AUTOMOTIVE	13-08	TRIMMER	02-03, 02-17
ALKALINE	11-03	DAT.	05-20, 20-35	HOLDERS	13-16	TUNING	02-03
BACKUP	11-07, 11-18	DV	20-34	GROMMETS	13-15	CAPTURE CARD TV & VIDEO	16-50
BIG JIM 6V	11-04	MICRO CASSETTES	05-20, 20-35	IDC	13-13	CAPTURE SURVEILLANCE DVR	21-33
BUTTON	11-07	SVHS	20-34	INSULATION TAPE	14-58	CAR AUDIO	18-02
BUTTON [TAGGED]	11-09	VHS & VHS-C	20-34	INTERCOMS	21-30	CROSS REFERENCE	18-74
CAMCORDER	11-32	BLANKING PLATE 240V	12-16	LOOM TUBING [AUTO]	18-28	ACCESSORY ADAPTORS	18-31
CAMERA [DIGITAL STILL]	11-44	BLOW TORCH	14-24, 13-19	MAINS [2 CORE]	13-12	ACCESSORY JACK & PLUG	18-44
CARBON	11-02	BLU RAY DISKS	20-37	MAINS [3 CORE]	13-12	ANTENNA	18-59
CELLULAR	11-54, 17-03	BLUETOOTH	16-86	MICROPHONE	13-03	ANTENNA ADAPTORS	18-72
CHARGERS	[SEE BELOW]	CAR KITS	18-14, 18-39	MICROPHONE [CURLY]	13-12	ANTENNA BOOSTER	18-36, 18-72
CLAMP CAR	18-42	COMPUTER ACC	16-86	MODULAR	13-12	ANTENNA CB RADIO	18-69
COMPUTER	11-08, 11-18	EARSETS [MOBILE PHONE]	17-08	NETWORKING	13-13	ANTENNA CELL PHONE	18-70
CORDESS DRILL	11-62	HANDS FREE KITS	17-09	OFFC	13-02, 13-11	ANTENNA CELL PHONE	19-19
CORDESS PHONE	11-22	HEADPHONES	06-06, 16-86, 17-08	PAIR IDENTIFIER	14-43	ANTENNA INPUT LEAD	07-40
CREATIVE LABS JUKEBOX	11-51	MOBILE PHONE	17-08	PHONE	13-12	ANTENNA TOOLS	18-50
CYCLON LEAD ACID	11-29	MOUSE	16-02	POWER	13-12	ANTENNA PLUGS	07-40, 18-72
DIGITAL STILL CAMERA	11-44	SOLAR HANDS FREE	17-11	PRINTER & CENTRONICS	16-112	ANTENNA X-REF	18-74
DVD-HDD RECORDER	11-09	TO SUPER SLIM VISOR	17-11	PULLER WIRE	14-17	CABLE	18-28
ELIMINATOR [240V TO 12V]	17-04	FM RADIO	17-10	REMOTE CONTROL VCR	04-98	CABLE KITS	18-26
GAMEBOY	11-49	USB DONGLE	16-86	RGB	13-04	CAPACITOR	18-30, 18-45
GPS	11-55	WIRELESS SPEAKERS	17-09	RIBBON - TV [300 OHM]	13-07	CIGAR LIGHT PLUG	07-21, 18-44
HAND HELDS	11-52	BNC		RIBBON - COMPUTER	13-13	CONVERTERS	18-36
HEARING AID	11-08	ADAPTOR	07-32	ROUTER - NO MODEM	16-95	CROSS-REFERENCE	18-12, 18-74
HOBBY PACK	11-20	ETHERNET	16-104	SECURITY	13-05, 21-05, 21-30	CROSSOVER PARTS	18-44
HOLDERS	11-70	LEADS	08-24	SERIAL LEADS D9 & D25	16-114	DIVERSITY ANTENNA	09-09, 18-68
INDUSTRIAL NICD/NIMH	11-14	PLUG & SOCKET	07-22	SHIELDED	13-02	FADER CONTROL	18-36
IPOD	11-50, 17-42	BOAT WHIP ANTENNA	19-19	SPEAKER	13-10	FLOATING GROUND ADAPTOR	18-36
ISOLATOR [CAR]	12-34	BOLTS & NUTS	14-69	SPIRAL WRAP	13-15, 18-48	FM MODULATOR	18-37
LANTERN 6V	11-04	BOLTS & NUTS [TRANSISTOR]	01-18	STAND OFFS	18-47	GAME CHARGERS	15-18
LANTERN RECHARGEABLE	11-15	BOOKS & SERVICE MANUALS	14-54	STRAIN RELIEF BOOT	07-27	GAME POWER [PS2]	15-09
LAPTOP	11-56	BOOKSHELF SPEAKERS	06-09	STRIPPER	13-15, 14-13	GAME POWER [PSP]	15-06
LEAD ACID	11-28	BOOSTED INDOOR ANTENNA	09-08	S-VHS	13-04	GAMEBOY POWER	15-17
LEADS [9V]	11-70	BOOSTED SPLITTER [AV & RF]	09-15	TELEPHONE	13-12	GROUND LOOP ISOLATER	18-36
LITHIUM	11-05	BOOSTER ANTENNA	09-08	TELEPHONE HANDSET	07-44	HARNES [GENERAL]	07-41
MEDIA PLAYER	11-51	BOOSTER ANTENNA [CAR]	18-36	TERMINAL STRIPS	07-42, 12-18	HARNES [SPECIAL]	18-53
MEMORY [WITH TAGS]	11-09	BOTTLE DISPENSER	14-64	TERMINATOR	07-05	IN DASH MOUNT KITS	18-12
MERCURY	11-07	BOX [FOR TOOLS]	14-19	TIDY	13-14	INTERCONNECT CABLE	18-29
MINI DISK	11-51	BRACKET [MOUNTING]	20-39	TIE TOOL	13-17, 14-12	IPOD CAR KIT	17-42, 18-37
MOBILE PHONE	11-54, 17-03	CAMERA ARMS	21-26	TIES	13-17, 18-48	ISO CONNECTS	18-53
MONITOR [12VDC]	11-21	COMMS ANTENNA	19-16	TV ANTENNA	13-06	KIT [CABLE]	18-26
NICAD CONSUMER	11-12	LCD & PLASMA MOUNT	20-39	TV ANTENNA FLYLEADS	08-25	LCD MONITORS	18-20
NIMH CONSUMER	11-12	MARINE ANTENNA	19-17	TWISTED PAIR	13-02	LCD MOUNT BRACKETS	18-18
NICD/NIMH TAGGED	11-14	MICROWAVE SUPPORT	20-48	VGA [AGGREGATE]	13-05	MOBILE PH. MOUNT	17-29, 18-14
NINTENDO	11-49, 15-18	SECURITY CAMERA	21-14	VIDEO	13-04, 21-30	MP3 FM MODULATOR	17-43, 18-37
PDA	11-51	SPEAKER STAND PA	06-27	VINTAGE CLOTH	13-08	NEON LIGHTS	18-24
PLAYSTATION PS3	15-09	SPEAKER	06-38, 20-44	WRAP	13-15, 18-48	NOISE SUPPRESSOR	18-30
PLAYSTATION PSP	11-49, 15-06	TV SUPPORT	20-44	CALIPER VERNIER	14-20	POWER CABLE KITS	18-26
POWER SOLDER IRON	14-25	WALL PLATE 240V	12-16	CAMCORDER		QUICK DISCONNECT	07-41
POWER TOOL	11-62	BRAID [SOLDER]	14-38	BATTERIES	11-32	QUICK DISCONNECT	18-34, 18-52
RACING	11-20	BRAKE PAD [VCR]	04-97	CASSETTE WINDER	04-101	RADIO SERVICE TOOLS	18-50
RECHARGEABLE PACK	11-20	BREADBOARD	01-17	CLEANING TAPE	20-35	MP3 PLAYER	18-37
SEALED LEAD ACID	11-28	BRIDGE RECTIFIERS	01-20	HEAD CLEANER [VHS]	04-100	SPEAKER CABLE	18-29
SIZES	11-16	BROADBAND ROUTER	16-89, 16-95	TAPES	20-34	SPEAKER INTERRUPTER	18-39
SLA CHARGER	11-30	BRUSHES [CLEANING]	14-64	VHS-C ADAPTOR	04-100	SPEAKER PROJECTS	18-39
SNAP	11-20	BRUSHES [PAINT]	14-17, 14-64	CAMERA		SPEAKER SPACER	18-06
TADIRAN	11-07	BULBS [LAMPS]	02-20	2.4GHZ WIRELESS	21-24	SPEAKER RCA CONVERTER	18-36
TAGGED	11-14	BULL BAR ANTENNA MOUNT	19-16	ARMS & SUPPORTS	21-26	SPEAKERS	18-02
TERMINAL	07-05, 07-43	BULLET CONNECTOR	07-43	BATTERY	11-05, 11-44	STEREO HARNES	07-41, 18-52
TERMINAL SNAP [9V]	11-70	BULLET TWEETER	06-67	BATTERY CAMCORDER	11-32	SUB-WOOFERS	18-02
TESTER	11-08	BURNER [DVD]	16-18	BOX & BULLET TYPE	21-18	SUB-WOOFER XOVER	18-36
TWO-WAY	11-58	BUTANE SOLDER IRON	14-25	CABLE [CAMCORDER]	08-22	TOOLS	14-02, 14-66, 18-50
UPS	11-29	BUTTON BATTERY	11-07	CABLE [SECURITY]	21-30, 21-30	TV ANTENNA	09-09
VCR BACKUP	11-18	BUTTON JVC VCR	04-97	CABLE [DIGITAL CAMERA]	08-23	USB FLASH PLAYER	18-37
VIDEO CAMCORDER	11-32	BUTYL TAPE	14-58	CASES	16-35	VIDEO CONVERT & TUNER	18-38
VIDEO CHARGER	11-35	BUZZERS	06-46, 21-28	CONTROLLERS	21-11	WIRING HARNES	18-52
XBOX	11-49			CLOTH [LENES]	14-62, 21-17	CAR-AUTOMOTIVE	
BATTERY CHARGERS				CUBE TYPE	21-19	12V DC TO DC CONVERTER	18-30
CAMERA	11-35			DOME	21-11	12V TO 240VAC INVERTER	18-33
CELLULAR	17-03			DOOR	21-02	12V TO DC CONVERTER	12-30
GAME	15-18			HOLE MOUNT	21-23	24V-12V CONVERTER	18-32
GAMEBOY	15-16			HOUSING	21-20	AIR COMPRESSOR	18-51
GENERAL PURPOSE	11-10			IP	21-19	ACCESSORY PLUG & JACK	18-44
HOBBY	11-21			IR SPOTLIGHT	21-17	ACCESSORY SPLIT	18-31
LEAD ACID	11-31			KITS	21-02, 21-24	ALLIGATOR CLIPS	18-43
MEDIA	17-42			LENES	21-21	ANTENNA	18-59
PLAYSTATION PSP	15-05			LIGHTING	21-17	ANTENNA ADAPTORS	18-72
SLA	11-30			MINIATURE	21-19, 21-23	ANTENNA GPS	18-68
UNIVERSAL VIDEO	11-43			OUTDOOR [SECURITY]	21-16	ANTENNA INPUT LEAD	07-40
VIDEO	11-35			PAN-TILT-ZOOM [PTZ]	21-11	ANTENNA PLUG	07-40
BATTERY POWER SPEAKER	17-45			PROFESSIONAL	21-12, 21-21	ANTENNA NEXT-G & GSM	18-70
BEAD INDUCTOR	02-17			REVERSING [CAR]	21-22	BATTERY CLAMPS	18-42
BEARING GREASE	14-61			SECURITY	21-11	BATT. ISOLATOR	12-34
BELT				SPY HOLE	21-23	BATTERY TERMINAL	18-42
AUDIO	05-02			WEBCAM	16-10, 21-07, 21-19	BLUETOOTH ACCESSORIES	17-08
CASSETTE	05-02			WIRELESS	16-12, 21-24	CABLE	13-08
CD	05-02			CANNON PLUG	07-08	CABLE CONNECT	18-34, 18-43
FLAT	05-03			CAPACITORS	02-02	CABLE HOLDERS	18-47
MICROWAVE	10-14			1 TO 3 FARAD [CAR]	18-30	CABLE KITS	13-09
SQUARE	05-02			BACKUP	02-12	CABLE SPLITTERS	18-42
TURNTABLE	05-03			CAN TYPE	02-12	CABLE TIES & WRAP	18-48
TYRES [VCR]	04-25			CAR AUDIO 1F TO 3F	18-30	CB ANTENNA BASES	19-14
VIDEO [VCR]	04-24			CERAMIC	02-03	CIRCUIT BREAKER	18-41
VIDEO KITS [VCR]	04-21			CROSS-OVER	02-4, 06-44	CROSS-REFERENCE	18-12, 18-74
BELT KIT				ELECTROLYTIC	02-08	DC SPLITTER	18-31
CLARION	05-05			FEED THRU	02-17	DC CONVERTERS	12-29, 19-31
VIDEO [VCR]	04-21			GOLD [BACKUP]	02-12	DISTRIBUTION BLOCK	18-42
BEZEL LAMP	02-20			IGNITION	18-30	FIXING BITS	18-46
BLADES				MAINS RATED	02-07	FUSE	02-24, 18-40
HACKSAW	14-14			METAL CAN	02-12	FUSE BLOCKS	18-40
JIGSAW	14-70			METALLISED POLYPROP	02-05	FUSE STANDARD	02-23
RETRACTABLE KNIFE	14-13			MICROWAVE	10-14	FUSE HOLDER	18-40
BLANK DISKS				NON POLAR	02-08	GAFFA TAPE	18-47
BLU-RAY	05-20, 16-25, 20-37			POLYESTER	02-06	GPS ANTENNA	18-68
CD-R/RW	05-20, 16-26, 20-38			POLYPROPYLENE	02-04	GSM ANTENNA	18-70
DAT	05-20, 16-26, 20-38			SILVER MICA	02-04	GPS & GSM ANTENNA	19-02
DVD-R/RW	05-20, 16-24, 20-36			SOLEIN TIN POLYPROP	02-04	HANDS FREE [MOB PHONE]	17-06
FLOPPY	16-26, 20-38			SPEAKER	06-44	HARNES [GENERAL]	07-41
BLANK TAPES				SURFACE MOUNT	02-11	HARNES [SPECIAL]	18-52
8MM VIDEO	20-34			TANTALUM	02-05	IGNITION FILTER	18-30, 19-07

## C

CABLE [ALSO SEE LEADS]	08-01
12V	13-08
300 OHM RIBBON	13-06
50 OHM COAX	13-06
75 OHM COAX	13-07
AC MAINS	12-15, 13-12
AGGREGATE [MULTICORE]	13-05
ALARM	13-12
AND LOCK ASSEMBLY	16-33
ANTENNA	13-06
AUDIO	13-02
AUTOMOTIVE	13-08, 18-26
AV	13-04
CAMERAS [SECURITY]	21-04, 21-30
CAR KIT	13-09, 18-26
CATS & CAT6	13-13
CLAMPS	12-18
CLAMPS [CHASSIS MOUNT]	07-41
CLIPS & TIES	12-18, 13-16
CLIPS [STICK ON]	13-17
CLOTH COVERED	13-08, 18-35
COAX [RF]	13-06
COAX [AUDIO]	13-02
COAX [SECURITY]	13-05, 21-30
COAX INSTALL CLIPS	13-17
COMMUNICATION	19-13
COMPUTER ETHERNET	16-99
CONNECTORS	07-02, 12-18
CRIMPING TOOLS	14-10
CURLY CORD	13-12
CUTTER	14-14
DATA	13-13
ETHERNET	13-13
FLAT [SPEAKER]	13-11
GENERAL	13-10
HARNES [CAR]	18-52
HARNES [PC POWER]	16-41
HEAT SHRINK TAPE	13-19
HEAT SHRINK TUBING	13-18, 18-48



IMPACT WRENCH . . . . .	18-51	IGNITION SUPPRESSOR . . . . .	19-07	SWABS . . . . .	14-65	CLEANING . . . . .	14-62, 16-78
INDICATOR & DIAL LAMPS . . . . .	18-35	LEADS POWER . . . . .	19-07	VIDEO HEAD . . . . .	14-65, 20-34	COOLING FANS . . . . .	16-80
ISO CONNECTORS . . . . .	18-53	LEADS RF . . . . .	19-12	VIDEO TAPE [VHS] . . . . .	04-100	COOLING FANS [CPU] . . . . .	16-58
LCD MONITORS . . . . .	18-20	MAGNETIC BASE . . . . .	19-16	WIPES . . . . .	14-62	CPU SWITCHBOX [KVM] . . . . .	16-52
LIGHTING ACCESSORIES . . . . .	18-24	MARINE ANTENNA . . . . .	19-20	CLEANING . . . . .	14-62, 16-78	D-TYPE PLUG . . . . .	16-106
MASKING TAPE . . . . .	18-47	MICROPHONE . . . . .	19-04	CLEANING SPRAY / SOLVENT . . . . .	14-66	D-TYPE LEAD . . . . .	16-114
PHONE BRACKETS . . . . .	18-15	PLUGS & SOCKETS . . . . .	07-40, 19-08	CLIPS CABLE . . . . .	13-17	D9/D15/D25 WALL PLATES . . . . .	16-105
PHONE HOLDERS . . . . .	18-14	POWER . . . . .	19-07	CLIPSAW WALL PLATES . . . . .	07-38	DATA SWITCH BOXES . . . . .	16-52
NEXT-G/3G ANTENNA . . . . .	18-70	SPEAKER EXTENSION . . . . .	19-06	CLOCK [DIGITAL TRAVEL] . . . . .	12-10	DESK MICROPHONE . . . . .	16-97
NOISE SUPPRESSOR . . . . .	18-30	SPRINGS [ANTENNA] . . . . .	19-15	CLOTH WIPES . . . . .	14-62	DVD DISKS . . . . .	16-24
ORNAMENTAL LIGHTING . . . . .	18-24	SWR & POWER METER . . . . .	19-17	CLOTH COVERED WIRE . . . . .	01-29, 13-08	DVD LABELS . . . . .	16-28
QUICK DISCONNECT . . . . .	07-41, 18-34	TAIL STRAP . . . . .	19-15	COAX CABLE . . . . .		DVI LEADS . . . . .	16-119
QUICK DISCONNECT KITS . . . . .	18-52	VOLTAGE REDUCER . . . . .	19-07	50 OHM & 75 OHM . . . . .	13-06, 13-07	DVR CARDS . . . . .	21-32
RELAY . . . . .	18-35	CCFL LAMP TESTER . . . . .	14-40	AUDIO . . . . .	13-02	ETHERNET CARD . . . . .	16-82
REVERSE SENSING KIT . . . . .	18-22	CCTV . . . . .	21-07	CLIPS . . . . .	13-17	ETHERNET SWITCH HUBS . . . . .	16-82
REVERSING CAMERAS . . . . .	21-22	CD . . . . .		COMMUNICATION . . . . .	13-06, 19-13	ETHERNET PRINT SERVER . . . . .	16-84
SCREWS . . . . .	18-46	ALIGNMENT . . . . .	05-19, 14-56	COMPUTER . . . . .	13-06	EXPRESS CARDS . . . . .	16-47
SOCKET & WRENCH TOOLS . . . . .	18-50	BELTS . . . . .	05-02	HOLDERS . . . . .	13-17	EXTENDER PRINTER D25 . . . . .	16-113
SPADE CONNECTOR . . . . .	07-43	BLANK MEDIA . . . . .	05-20, 20-38	LL195 & LL400 . . . . .	17-21, 19-13	EXTENDER USB 5M . . . . .	16-127
SPADE CONNECTOR . . . . .	18-34	CAR ADAPTOR . . . . .	05-21, 18-37	RG174U . . . . .	13-06, 17-21	EXTEND OVER ETHERNET . . . . .	16-55
SWITCH . . . . .	02-31, 18-44	CASE . . . . .	05-21, 16-28	RG213U . . . . .	13-06, 17-21	EXTERNAL HDD . . . . .	16-19
TAIL STRAPS . . . . .	18-67	CD-R . . . . .	16-26, 20-38	RG58 & RG59 [A/AU/CU] . . . . .	13-06	EXTERNAL MEDIA SERVER . . . . .	16-21
USB ACCESSORIES . . . . .	16-17	CD-ROM AUDIO LEAD . . . . .	16-42	RG6 . . . . .	13-07	EXTERNAL STORAGE . . . . .	16-21
CAR RADIO TOOLS . . . . .	18-50	CD-RW . . . . .	16-26, 20-38	SECURITY . . . . .	13-05, 21-05, 21-30	FAN . . . . .	16-62
CARBON . . . . .		CLEAN & REPAIR KITS . . . . .	05-18	STRIPPER TOOL . . . . .	14-13	FAN CPU COOLERS . . . . .	16-58
BATTERY . . . . .	11-02	DISKS . . . . .	20-38	TIES . . . . .	13-17	FAN HARD-DRIVE . . . . .	16-61
RESISTORS . . . . .	02-14	FLAT CABLE CONNECTOR . . . . .	05-09	TV ANTENNA . . . . .	13-06	FAN ALARM & SENSOR . . . . .	16-61
TUNING TRACKS . . . . .	03-02	HOLDER . . . . .	05-21	TWISTED PAIR . . . . .	13-02	FAN GUARDS . . . . .	16-61
CARLING SWITCH . . . . .	02-31	JEWEL CASE . . . . .	05-21	VIDEO . . . . .	13-04, 21-30	FAN POWER LEADS . . . . .	16-61
CARMAX [MOBILE PHONE] . . . . .	17-03	LABELLING . . . . .	16-35	WRAP . . . . .	13-15, 18-48	FIBRE OPTIC NETWORK . . . . .	16-85
CAROUSEL MOTORS [MWO] . . . . .	10-13	LASER . . . . .	05-10	COAX FLYLEADS [TV ANT] . . . . .	08-25	FIREWIRE ADAPTORS . . . . .	16-125
CARRY CASE TO SUIT . . . . .		LENS CLEANER DISK . . . . .	05-18, 20-34	COBY HEADPHONES . . . . .	06-04	FIREWIRE CARD . . . . .	16-125
CD & DVD . . . . .	05-21, 16-29	LOADING BELTS . . . . .	05-02	COCHLEAR IMPLANT BATTERY . . . . .	11-08	FIREWIRE LEADS . . . . .	16-125
GAMEBOY . . . . .	15-17	MANUAL . . . . .	14-55	COILS . . . . .	02-13, 03-03	FLASH DRIVE USB READER . . . . .	16-27
LAPTOP & NOTEBOOK . . . . .	16-30	MECHANISM . . . . .	05-09	COLOUR BAR GENERATOR . . . . .	14-39	FLOPPY DISKS . . . . .	16-26
MULTI-METER . . . . .	14-49	MEMBRANE . . . . .	05-09	COLOUR MODULES VCR . . . . .	04-97	FLOPPY DRIVE . . . . .	16-18
NINTENDO WII . . . . .	15-03	MINI CDR . . . . .	20-38	COMBINATION TOOL SETS . . . . .		GAMEPAD . . . . .	16-07
PLAYSTATION PSP . . . . .	15-04	MOTORS . . . . .	05-08	GENERAL . . . . .	14-09	GENDER CHANGERS CAT5 . . . . .	16-98
TOOL BOX . . . . .	14-19	PLAYER LASER CLEANING . . . . .	20-34	SCREWDRIVER . . . . .	14-03	GENDER CHANGERS D . . . . .	16-108
CARTRIDGE [TURNTABLE] . . . . .		REPAIR KIT . . . . .	05-18	UNIVERSAL MINI . . . . .	14-07	GENDER CHANGERS USB . . . . .	16-126
HEAD SHELL . . . . .	05-24	RE-WRITEABLE DISKS . . . . .	16-26, 20-38	COMMUNICATION . . . . .	19-01	HARD DISK COOLING . . . . .	16-19
RECORD PLAYER . . . . .	05-23	SERVICE MANUAL . . . . .	14-55	24V-12V CONVERTER . . . . .	19-07	HARD DISK DRIVE 2 1/2" & 3 1/2" . . . . .	16-22
SCREWS . . . . .	05-24	STORAGE & CASES . . . . .	05-21	ACOUSTIC EAR TUBE . . . . .	19-05	HARD DISK EXTERNAL . . . . .	16-19
STYLUS . . . . .	05-25	TEST DISK . . . . .	05-19, 14-56	ADAPTORS . . . . .	19-10	HARD DISK IDE SATA LEADS . . . . .	16-43
TURNTABLE . . . . .	05-23	TO CAR CASSETTE ADAPT . . . . .	05-21	ANTENNA BASES . . . . .	19-14	HARD DISK JUMP CONNECT . . . . .	16-42
WIRES . . . . .	05-24	WALLET [STORAGE] . . . . .	05-21	ANTENNA MOUNTS . . . . .	19-16	HARD DISK MOUNTING . . . . .	16-18
CASE . . . . .		WRITEABLE . . . . .	05-20, 16-26, 20-38	ANTENNA PATCH LEADS . . . . .	19-12	HARD DISK POWER CABLE . . . . .	16-42
ATTACHÉ . . . . .	14-19	CEILING CUTTER . . . . .	14-18	ANTENNA SWITCH . . . . .	19-17	HDD 2 1/2"/3 1/2" ADAPTOR . . . . .	16-43
CD & DVD STORAGE . . . . .	05-21	CEILING ROSE . . . . .	12-14	ANTENNA COAX . . . . .	19-13	HDD & PCB JUMPER PLUGS . . . . .	16-42
GAMEBOY . . . . .	15-16	CEILING SPEAKER . . . . .	06-14	ATTENUATOR . . . . .	19-17	HARNESS POWER & MOLEX . . . . .	16-41
GPS . . . . .	17-12	CELLULAR [MOBILE PHONE] . . . . .	17-01	BATTERIES . . . . .	11-58	HEADSET W/ MIC . . . . .	16-08
MOBILE PHONE . . . . .	17-02, 17-36	CELLULAR PHONE BATT . . . . .	11-54, 17-03	CABLE . . . . .	13-06, 19-13	HEATSINK [PC & CPU] . . . . .	16-58
PSP . . . . .	15-04	CELLULAR PHONE MIC . . . . .	06-29, 17-39	CONNECTORS . . . . .	19-08	HEATSINK COMPOUND . . . . .	16-61
CASSETTE . . . . .		CENTRE SPEAKER KIT . . . . .	06-107	CB ACCESSORIES . . . . .	19-04	HUBS ETHERNET . . . . .	16-82
ADAPTOR VHS-C . . . . .	04-100	CENTRE SPEAKER IN-WALL . . . . .	06-14	DUMMY LOAD . . . . .	19-17	HUBS USB . . . . .	16-126
AUDIO TEST . . . . .	05-19	CENTRONICS . . . . .		GPS & GSM ANTENNA . . . . .	19-02	IDE LEADS . . . . .	16-43
BELTS . . . . .	05-02	ETHERNET SERVER . . . . .	16-84	H ACCESSORIES . . . . .	19-05	IDC CABLE & PLUGS . . . . .	16-105
CD CAR ADAPTOR . . . . .	05-21	LEADS . . . . .	16-113	HEADSETS . . . . .	19-05	IDC CRIMP PLUG . . . . .	16-105
CLEANER AUDIO . . . . .	05-20	PLUGS . . . . .	16-106	LEADS . . . . .	19-12	IDC CRIMP TOOL . . . . .	16-81
CLEANER VIDEO . . . . .	04-100	USB CONVERTER . . . . .	16-16	LIGHTNING ARRESTER . . . . .	19-17	IDC PUSH TOOL [KRONER®] . . . . .	16-80
DAT AUDIO . . . . .	05-20	CERAMIC . . . . .		MICROPHONES . . . . .	19-04	IEEE-1394/A/B FIREWIRE . . . . .	16-125
ENDLESS . . . . .	05-20	ALIGNMENT TOOL . . . . .	14-07	PLUGS & SOCKETS . . . . .	19-08	IEEE-1394 PCI/e CARDS . . . . .	16-46
HEADS . . . . .	05-04	CAPACITORS . . . . .	02-03	POWER LEADS . . . . .	19-07	IP CAMERAS . . . . .	16-11
HEAD CLEANER [AUDIO] . . . . .	05-20	CARTRIDGE [PHONO] . . . . .	05-23	POWER SUPPLY . . . . .	19-07	IPODCONNECT . . . . .	16-129, 17-40
HEAD CLEANER [VCR] . . . . .	04-100	FILTER . . . . .	02-16	SPEAKER . . . . .	19-06	IRDA TO USB TRANCEIVER . . . . .	16-14
IDLERS . . . . .	05-05	FUSE . . . . .	02-23	VSWR & POWER METER . . . . .	19-17	JOYSTICK & GAMEPAD . . . . .	16-07
MICRO-AUDIO . . . . .	05-20	RESONATOR . . . . .	02-16	COMPACT FLASH CARDS . . . . .	16-27	JUMPER CONNECTS . . . . .	16-42
MINI DV . . . . .	20-34	SCREWDRIVER . . . . .	14-07	COMPACT FLASH READER . . . . .	16-27	KEYBOARD . . . . .	16-04
MOTORS . . . . .	05-06	TRAP . . . . .	02-16	COMPONENT VIDEO [See YUV] . . . . .		KEYBOARD ADAPTOR . . . . .	16-108
PINCH ROLLERS . . . . .	05-05	CF MEMORY CARD . . . . .	16-27	CABLE . . . . .	07-02, 13-04	KEYBOARD EXTENDER . . . . .	16-109
TAPES . . . . .	05-20, 20-35	CHAMOIS HEAD CLEANER . . . . .	14-65	CONVERTERS . . . . .	20-07	KEYPAD ADD-ON . . . . .	16-03
TEST TAPE . . . . .	05-19	CHAMOIS SWABS . . . . .	14-65	LEADS . . . . .	08-12	KVM-KEYBOARD-VIDEO-MOUSE . . . . .	16-51
TEST TAPE [VCR] . . . . .	04-99	CHARGE-N-GO [MOBILE] . . . . .	17-03	OVER CAT5 . . . . .	20-24	KVM EXTENDER . . . . .	16-56
VIDEO TAPE . . . . .	20-34	CHARGERS [BATTERY] . . . . .		PLUGS . . . . .	07-02	KVM MINI . . . . .	16-53
VIDEO TAPE CLEANER . . . . .	04-100	CAMCORDER . . . . .	11-35	TO DVI OR HDMI CONVERT . . . . .	16-69	LAN CABLE TESTER . . . . .	16-81
CAT5/e & CAT6/e . . . . .		CELLULAR . . . . .	17-03	COMPONENT TRAYS . . . . .	14-69	LAPLINK® TRANSFER LEAD . . . . .	16-116
ADAPTORS . . . . .	16-98	GAME . . . . .	15-05, 15-16, 15-18	COMPOUND . . . . .		LAPTOP [SEE LAPTOP] . . . . .	16-30
BOOTS . . . . .	16-100	GENERAL . . . . .	11-10	HEAT . . . . .	14-61	LEADS ETHERNET . . . . .	16-99
CABLE . . . . .	13-13, 16-101	GPS . . . . .	17-12	SILICON . . . . .	14-61	LEADS GENERAL . . . . .	16-109
CONNECTOR PLUGS . . . . .	16-100	HOBBY . . . . .	11-21	COMPRESSOR [AIR] . . . . .	18-51	LEADS KVM . . . . .	16-53
CRIMPING TOOL . . . . .	16-80	LEAD ACID . . . . .	11-30	COMPRESSOR [AIR] . . . . .	16-01	LEADS NETWORK & CAT5/6e . . . . .	16-99
CROSS-OVER ADAPTOR . . . . .	16-99	MOBILE PHONE . . . . .	17-03	ADAPTORS D-PLUGS . . . . .	16-106	LEADS OPTICAL FIBRE . . . . .	16-85
CROSS-OVER LEAD . . . . .	16-99	SUPER . . . . .	11-10	ADSL ACCESS . . . . .	16-97	LEADS POWER AC & UPC . . . . .	16-40
DUPLEXER MODULE . . . . .	16-99	UNIVERSAL VIDEO . . . . .	11-43	ADSL ROUTERS . . . . .	16-95	LEADS POWER DC MOLEX . . . . .	16-41
ETHERCON XLR . . . . .	16-100	CHOKES RF . . . . .	02-13	APPLE LEADS . . . . .	16-112	LEADS SCSI . . . . .	16-110
ETHERNET CARD . . . . .	16-82	CHROMA PCB [VCR] . . . . .	04-97	BATTERY [BACKUP] . . . . .	11-08, 11-18	LEADS USB . . . . .	16-127
ETHERNET HUB . . . . .	16-82	CIGARETTE LIGHTER PLUG . . . . .	07-21	BATTERY [LAPTOP] . . . . .	11-56	LEADS WIFI ANTENNAE . . . . .	16-97
INTERCONNECTS . . . . .	16-99	CIRCUIT . . . . .		BATTERY [PDA] . . . . .	11-52	MIDI USB & BREAK-OUT LEAD . . . . .	16-116
KEYSTONE . . . . .	16-101	BOARD [VERO-BOARD] . . . . .	01-17	BLANK DISKS . . . . .	16-24	MEDIA [BLANK] . . . . .	16-24
KRONE TOOL . . . . .	16-80	BREAKER AUTOMOTIVE . . . . .	18-41	BLUETOOTH . . . . .	16-86, 17-08	MEDIA CENTRE REMOTE . . . . .	16-06
LEADS . . . . .	16-99	BREAKER PANEL MOUNT . . . . .	12-16	BNC ETHERNET . . . . .	16-104	MEDIA NAS SERVER IN-A-BOX . . . . .	16-21
MOUNTING BOXES . . . . .	16-102	CLEANER . . . . .	14-66	CABLE [COAX] . . . . .	13-06, 17-21	MEMORY CARDS . . . . .	16-27
NETWORK CARDS . . . . .	16-82	INTEGRATED . . . . .	01-08	CABLE [ETHERNET] . . . . .	13-13	MEMORY CARD READER . . . . .	16-14/18
OVER MAINS 240VAC . . . . .	16-99	PROTECTORS . . . . .	02-24	CABLE [IDC] . . . . .	13-13	MICROPHONE . . . . .	16-08, 16-97
PATCH LEADS . . . . .	16-99	CLAMP METER . . . . .	14-45	CABLE [MONITOR] . . . . .	13-05	MOBILE PHONE CONNECT . . . . .	17-16
PLUGS . . . . .	16-100	CLAMP SCISSOR . . . . .	14-17	CABLE ETHERNET CAT5/6e . . . . .	16-99	MODEM [DIAL UP] . . . . .	16-95
POCKET CABLE . . . . .	16-99	CLARION CAR STEREO PARTS . . . . .	05-07	CARDS . . . . .	16-46, 16-48	MODEM [ADSL] . . . . .	16-95
PUNCH DOWN TOOL . . . . .	16-80	CLAW HAMMERS . . . . .	14-17	CATS CABLE . . . . .	13-13	MODEM CONNECT LEADS . . . . .	16-114
RACK MOUNT . . . . .	16-83	CLEANER . . . . .		CATS LEADS . . . . .	16-99	MODULAR ADAPTOR FILTER . . . . .	16-98
SURFACE MOUNT . . . . .	16-101	CASSETTE AUDIO . . . . .	05-20, 20-35	CATS PLUG . . . . .	16-100	MONITOR DVI LEADS . . . . .	16-119
TESTER . . . . .	16-81	CASSETTE VIDEO . . . . .	20-34	CATS PUNCH DOWN . . . . .	16-80	MONITOR VGA LEADS . . . . .	16-117
WALL PLATES . . . . .	16-102	CASSETTES VCR . . . . .	04-100	CAT5 RACK . . . . .	16-83, 16-102	MONITOR CRT LOPT . . . . .	03-17
CB . . . . .		CD . . . . .	05-18	CAT6 CABLE . . . . .	13-13, 16-99	MONITOR CLEANERS . . . . .	16-78
24V TO 12V REDUCER . . . . .	19-07	CLOTHS . . . . .	14-62	CD & DVD AUDIO LEADS . . . . .	16-42	MONITOR SUPPORT STAND . . . . .	16-34
ACCESSORIES . . . . .	19-04	DISKS [CD/DVD PLAYER] . . . . .	20-34	CD & DVD BELTS . . . . .	05-02	MONITOR SELECT SWITCH . . . . .	16-52
ANTENNA BASES . . . . .	19-14	DVD . . . . .					



COMPUTER *Continued...*

NETWORK CABLING CAT5/6e 16-99  
 NETWORK TEST/TRACE 16-81  
 NETWORK HUBS 16-82  
 NETWORK WIFI 16-88  
 NOTEBOOK [SEE NOTEBOOK] 16-30  
 NUMERIC KEYPAD ADD-ON 16-03  
 OPTICAL FIBRE ETHERNET 16-85  
 PAPER [PHOTO & CD/DVD] 16-35  
 PATA TO SATA 16-46  
 PATCH LEADS AUDIO 16-42  
 PATCH LEADS CAT5/6e 16-99  
 PATCH PANEL CAT5/6e 16-83  
 PC-VGA TO TV CONVERTER 16-75  
 PCB SHUNT JUMPERS 16-42  
 PCI / PCIe CARDS 16-48  
 PCMCIA CARDS 16-46  
 PDA TO USB ADAPTOR 16-129  
 PLUGS "D" & CENTRONIC 16-105  
 PLUGS PCB HDMI PS2 USB 16-107  
 PLUGS RJ45 CAT5/6e 16-100  
 PLUGS WIFI 16-92  
 POE [power over ethernet] 16-84  
 POWER ADAPTORS 16-41  
 POWER BOARDS 240AC 16-36  
 POWER CHECK 16-41  
 POWER CORDS 240AC 16-40  
 POWER LEAD HDD 16-42  
 POWER LEAD MOLEX 16-41  
 POWER PROTECTION 16-36  
 POWER SUPPLY ATX 16-41  
 POWER LAPTOP, ETC. 12-22, 16-32  
 POWER UPS 16-38  
 PRINTER LEADS 16-113  
 PRINTER SERVER 16-84  
 PS2 ADAPTOR & LEAD 16-109  
 PS2 KEYBOARD & MOUSE 16-02  
 PS2 KVM 16-53  
 RAID SERVER IN-A-BOX 16-21  
 REMOVABLE HDD RACK 16-19  
 RF REMOTE PRESENTER 16-07  
 RJ45 CABLE BULK REELS 16-101  
 RJ45 LEADS ETHERNET 16-99  
 RJ45 PLUGS CAT5/6e 16-100  
 RJ45 TOOLS 16-80  
 RJ45/RJ12 KIT 16-97  
 ROUTER 16-89  
 ROUTER & ADSL MODEM 16-95  
 RS232 ADAPTORS 16-107  
 RS232 EXTENDER 16-56  
 RS232 LEADS 16-114  
 RS232 PLUGS 16-107  
 RS232 SWITCH BOX 16-52  
 SAS CABLES 16-44  
 SATA & eSATA CABLES 16-43  
 SATA TO PATA 16-46  
 SCREEN DISPLAY CLEANER 16-78  
 SCREW KIT 16-18  
 SCSI ADAPTOR 16-110  
 SCSI LEADS 16-110  
 SCSI PLUGS 16-106  
 SERVER ETHERNET MODULE 16-84  
 SERIAL LEADS 16-114  
 SIM CARD READER 16-14  
 SIM PLATE KEYSTONE 16-103  
 SOUND CARD [PCI] 16-50  
 SPEAKERS 16-09  
 STORAGE DATA SERVER 16-21  
 SUN-MICRO LEAD 16-117  
 SURGE PROTECTION 16-36  
 SWITCH SELECT BOXES 16-52  
 SWITCH PC ATX POWER 16-41  
 TESTER POWER 16-41  
 TESTER CAT5/6e NETWORK 16-81  
 THERMAL CONTROL LAPTOP 16-33  
 THERMAL CONTROL CPU FAN 16-58  
 TOOLS 14-01, 16-80  
 TV TUNER CARD [PCI] 16-49  
 TV TUNER BOX TO VGA 16-77  
 UPS 16-38  
 USB ACCESSORIES 16-13  
 USB ADAPTOR 16-16, 16-126  
 USB HUBS 16-126  
 USB LEADS 16-127  
 USB MEMORY STICK 16-27  
 USB TO SATA 16-46  
 USB TRAVEL KIT 16-128  
 VGA CONVERTER 16-72  
 VGA LEADS 16-117  
 VGA EXTEND & SPLITTER 16-55  
 VGA SWITCHING 16-56  
 VIDEO CONVERT 16-12, 16-15, 16-50  
 VIDEO CAPTURE 16-12, 16-49, 16-77  
 VIDEO CAPTURE 16-50, 21-32  
 VIDEO CARD 16-50  
 VIDEO MIXER EDITOR 16-76  
 VIDEO TO VGA CONVERTER 16-72  
 VOIP 16-96  
 WALL PLATES 16-101, 16-105  
 WEBCAM 16-10  
 WIFI ANTENNA & CABLES 16-90  
 WIRELESS BROADBAND 16-89  
 WIRELESS NETWORKING 16-88  
 CONCRETE SET 14-18  
 CONDUCTIVE  
 GLUE GREASE & PAINT 14-60  
 PEN FOR PCB REPAIR 14-60  
 CONDUIT CUTTER 14-15

CONNECTORS

AV 07-01  
 BULLET & SPADE 18-34, 18-42  
 CAT5/6e 16-100  
 COMMUNICATION 7-22, 19-08  
 COMPUTER [D-TYPE] 16-105  
 COMPUTER [BNC] 16-104  
 LASER MEMBRANE 05-09  
 RJ12, RJ45 07-45, 16-100  
 WIFI 16-92  
 CONTACT CLEANER 14-66  
 GREASE 14-61  
 LUBRICANTS 14-66  
 CONTROL HEAD [VCR] 04-09  
 CONTROLLER  
 GAME [PC] 16-07  
 PLAYSTATION 15-08  
 PLAYSTATION [WIRELESS] 15-07  
 SECURITY SYSTEM 21-11  
 XBOX 15-12  
 CONTROLS [REMOTE] 20-15  
 CONVERTER  
 12-240V INVERTER 18-33  
 240VAC INVERTER 12-34  
 AUDIO TO DIGITAL 20-10  
 COAX TO OPTICAL 08-03  
 COLOR SYSTEM 20-08  
 COMPONENT TO DVI & HDMI 16-69  
 COMPONENT TO RGB 20-07  
 DIGITAL FORMAT 20-08  
 DVI TO VGA 16-71  
 GAMES TO TV RF 15-18  
 HDMI TO DVI & SPDIF 16-68  
 LINE TO PHONO 05-22  
 MULTI SYSTEM VIDEO 20-08  
 OPTICAL TO COAX 08-03  
 PAL TO NTSC 20-08  
 PC-VGA TO TV 16-75, 20-06  
 PHONO INPUT 05-22  
 PHONO TO LINE 20-10  
 RF MODULATOR 09-13, 20-32  
 RF MODULATOR [GAME] 15-18  
 RGB TO COMPONENT 20-07  
 RS232-RS485 21-10  
 RS485 PROTOCOL 21-10  
 SCART RGB TO XGA 16-73  
 SPEAKER TO RCA LINE 18-36  
 S-VHS TO SCART 07-31  
 USB TO PARALLEL 16-16  
 USB TO SERIAL 16-16  
 USB TO VGA 16-12, 16-77  
 VGA TO COMPONENT 16-75  
 VGA TO DVI 16-69  
 VGA TO HDMI 16-69  
 VGA TO VIDEO 16-75  
 VIDEO TO CAT5 20-24  
 VIDEO TO DVI 16-70  
 VIDEO TO USB 16-12, 16-15  
 VIDEO TO VGA 16-72, 20-04, 20-06  
 VIDEO TO XGA 16-73, 20-06  
 VIDEO TO SXGA 16-74  
 COOLING FAN FINGER GUARD 16-61  
 COOLING FANS 16-62  
 COOLING FANS [CPU] 16-58  
 COPPER WICK 14-38  
 CORDLESS  
 DRILL BATTERY 11-62  
 DOORBELL 21-27  
 HEADPHONES 06-03  
 PHONE ANTENNA [PANA] 09-09  
 PHONE BATTERY 11-22  
 SCREWDRIVER 14-03  
 SOLDER IRONS 14-25  
 CORE INDUCTOR 03-03  
 COTTON BUDS / TIPS 14-65  
 GLOVES 14-57, 14-65  
 SWABS 14-65  
 COVER MOBILE PHONE  
 HOUSING 17-39  
 LEATHER/PLASTIC CASE 17-36  
 CRADLE MOBILE PHONE & GPS  
 HOLDER 17-29  
 CRESCENT TOOLS 14-13  
 CRC SERVICE AIDS 14-67  
 CRIMP  
 ANTENNA PLUGS 07-22  
 COMMUNICATION PLUGS 19-08  
 ETHERNET PLUGS BNC 16-104  
 ETHERNET PLUGS RJ45 16-100  
 TOOLS 14-10  
 WIFI PLUGS 16-92  
 CROCODILE CLIPS 07-19  
 CROCODILE LEADS 14-51  
 CRO-PROBES 14-50  
 CROSSOVER PARTS 06-44  
 SPEAKER 06-42  
 SUBWOOFER 06-40  
 CRT DEGAUSER 14-40  
 CRT REJUVENATOR 14-40  
 CRT SOCKET 03-04  
 CRT YOKE 03-04  
 CRYSTAL EARPIECE 06-07  
 CRYSTALS 02-17  
 CUBE SPEAKER 06-10  
 CURLY CORD 13-12  
 CURLY CORD [TELEPHONE] 07-45  
 CUT OFF [THERMAL] 02-18  
 CUTTING KNIVES 14-13  
 CYCLON BATTERY PACKS 11-29

## D

DA-SACK BUM BAG 17-02  
 DAHICHI SPEAKER 06-52  
 DAT AUDIO  
 HEAD CLEANER 05-20, 20-35  
 TAPES 05-20, 20-35  
 DATA www.wescomponents.com/data  
 DATA LOG 14-44, 14-46  
 DATA MANUAL 14-54  
 DATA TRANSFER CABLE 16-116  
 DC  
 12V-240 INVERTOR 12-33, 18-33  
 24V-12V REDUCER 12-33, 18-32  
 CONVERTERS 18-30  
 PLUGS 07-20  
 POWER PACKS 12-22  
 DEANS ULTRA PLUGS 11-21  
 DECADE BOX 14-49  
 DEFLECTION CIRCUIT FOR CRT  
 MANUAL 14-55  
 YOKE 03-04  
 DEGAUSSING WAND 03-05, 14-40  
 DEGREASER 14-66  
 DELAY LINE [TV] 03-02  
 DELUXE FINDER TOOL 14-17  
 DENTIST MIRROR 14-22  
 DESK LAMP 14-23  
 DESK MICROPHONE 06-33, 16-97  
 DESOLDER  
 AID TOOLS 14-37  
 BRAID 14-38  
 BRUSHES 14-21  
 FUME EXTRACTOR 14-35  
 PISTOL GUN 14-34  
 SMD 14-30  
 SMD REMOVAL TOOLS 14-37  
 SMD REMOVAL KIT 14-34  
 STATION 14-32  
 DIEMEN TRANSFORMERS 03-10  
 DIAL CORD 05-06, 13-15  
 DIGITAL  
 CAMERA BATTERY 11-44  
 CAMERA INTERCONNECTS 08-23  
 CLOCK [TRAVEL] 12-10  
 COAX LEADS 08-02  
 FORMAT CONVERTER 20-08  
 LEADS [HI QUALITY] 08-12  
 METERS 14-44  
 SET TOP BOX 20-02  
 TAPES 20-34  
 THERMOMETER 14-48  
 TIMER [AC POWER] 12-08  
 TOSLINK LEADS 08-02  
 TV MANUAL 14-55  
 DIMMER LIGHT [240VAC] 12-16  
 DIN PLUGS & SOCKETS 07-13  
 DIODE 01-21  
 BRIDGE 01-20  
 FLASHING 01-22  
 INFRA-RED 01-22  
 LED 01-22, 01-24  
 MICROWAVE 10-09  
 PACK 01-20  
 PHOTO 01-22, 01-24, 04-96  
 VIDEO SENSOR 04-96  
 ZENER 01-20  
 DIPLEXER 09-02, 09-16  
 DIPOLE ANTENNA 09-08  
 DISHWASHER MANUAL 14-54  
 DISK  
 HARD DRIVE [HDD] 16-22  
 BLURAY 16-25, 20-37  
 CASE & CARRY SOLUTIONS 16-28  
 CLEANERS 05-18, 16-78  
 CLEANING DISKS 05-18, 16-78  
 CD-R/RW [BLANK] 16-26, 20-38  
 CD-R MUSIC [BLANK] 05-20  
 DRIVE [CD / DVD BURNER] 16-18  
 DRIVE [FLOPPY] 16-18  
 DRIVE [HDD EXTERNAL] 16-19  
 DVD-R/RW [BLANK] 16-24, 20-36  
 FLOPPY DISK 16-26, 20-38  
 LABELS 16-35  
 MINI [BLANK] 20-37  
 STORAGE 16-28  
 DISPENSER BOTTLE & PEN 14-36/64  
 DISPLAY SCREEN MOUNTING 20-39  
 DISTRIBUTION  
 AMP [ANTENNA] 09-15, 09-18  
 AUDIO - VIDEO 09-16  
 AV 20-14, 20-28  
 AV SWITCH BOXES 09-16, 20-10  
 BLOCK AUTOMOTIVE 18-41  
 TV AMPLIFIER 09-15  
 DJ MIXERS 05-22, 06-22  
 DOME CAMERAS 21-11  
 DOOR  
 BELL [WIRELESS] 21-27  
 CAMERA 21-02, 21-23  
 CATCH [TV/CD/VCR] 02-29, 05-06  
 INTERCOM 21-02, 21-27  
 LINING [MICROWAVE] 10-07  
 LOCKING CATCH 03-08, 04-98  
 STRIKE OPENER 21-06, 21-27  
 SWITCHES [MICROWAVE] 10-08  
 VIDEO PHONE 21-02

DOORWAY BEAM / EYE 21-29  
 DOUBLE  
 ADAPTOR MAINS 240V 12-11  
 ADAPTORS [AV] 07-30  
 SIDED TAPE 13-14, 14-59, 18-47  
 DRILL  
 BATTERIES 11-62  
 BIT KITS 14-18  
 BITS 14-70  
 CHUCK 14-19  
 CORDLESS SCREWDRIVER 14-03  
 DRIVE BELTS  
 AUDIO 05-02  
 VCR 04-21  
 DRIVESAFE - CELL PHONE 17-07  
 DRYER SERVICE MANUAL 14-54  
 DUBBING KIT [VCR] 08-24  
 DUBBING MOTORS 05-07  
 DUCT TAPE 14-58  
 DUMMY LOAD RESISTOR 02-15, 19-17  
 DUST BLOW 14-64  
 DUST-GO CLOTH 14-63  
 DVD  
 CASE & HOLDERS 05-21, 16-28  
 CLEANING KIT 05-18  
 DISKS 05-20, 16-24, 20-36  
 DRIVE [PC] 16-18  
 LABELLING 16-35  
 LASER ASSEMBLIES 05-10  
 LENS CLEANER 05-18, 20-34  
 LIGHTSCRIBE DVD-R 20-36  
 MEDIA 20-36  
 RAM DISKS 20-37  
 RF MODULATOR 09-13, 20-32  
 STORAGE 05-21, 16-28  
 SPARE PARTS DVD PLAYER 05-08  
 SPARE PARTS LASER 05-10  
 TEST DISK 05-19  
 TO OLD TV ADAPTOR 09-13, 20-32  
 UPS CALER & CONVERTER 16-66  
 VIDEO STABILISER 09-15, 20-05  
 DVI  
 ADAPTOR PLUGS/LEADS 16-120  
 BOOSTER REPEATER 16-66  
 CONVERTER 16-68  
 LEADS 08-04  
 LEADS 16-119  
 REPEATER BOOSTER 16-66  
 SCALERS 16-70  
 SPLITTERS 16-66, 20-14  
 SWITCHES 16-66, 20-12  
 WALL PLATE 16-120  
 DVR 21-07, 21-19  
 DVR [PROFESSIONAL] 21-32  
 E  
 EAR  
 BUDS 06-07, 17-44  
 PADS 06-08  
 PIECE 06-07  
 SETS 06-08, 16-08, 17-08  
 EARTH LEAKAGE PROTECT 12-09  
 EHT  
 CD LISTING 03-08  
 LEAD 03-07  
 PROBE 03-08  
 TESTER 03-06  
 TRANSFORMER 03-10  
 TRIPLER 03-06  
 EIAJ PLUGS & SOCKETS 07-20  
 ELECTROLYTIC CAPACITORS 02-08  
 ELECTRET MIC 06-29  
 ELECTRONIC TIMERS 12-08  
 ELECTRONIC TOOL WALLET 14-09  
 ELECTROBLUE SERVICE AIDS 14-67  
 ELECTROSTATIC - SEE ANTISTATIC  
 EMF TESTER 14-48  
 EMI FERRITE CORES 02-17  
 ENDLESS CASSETTE TAPE 05-20  
 ENERGY SAVING LAMP 12-10  
 ENTRY  
 ALARMS & MONITORS 21-02  
 DOOR BELL 21-27  
 DOOR STRIKE 21-06, 21-27  
 DOORWAY BEAM 21-29  
 KEYPAD 21-27  
 EPOXY CONDUCTIVE GLUE 14-37  
 ETHERNET  
 CABLE CAT5E / 6 13-13, 16-99  
 CARD PCI INSIDE PC 16-49  
 CARD PCMCIA CARD 16-47  
 HUBS 16-82  
 KEYSTONE 16-101  
 LEADS CAT5/6e 16-99  
 OPTICAL 16-85  
 PLUGS 16-100  
 RACK PATCH PANEL 16-101  
 TOOLS 16-80  
 USB 16-16, 16-84  
 ETHYLENE GLYCOL COOLANT 03-09  
 EXPANDER - JAPAN FM 18-36  
 EXT STORAGE MEDIA PLAYER 20-04  
 EXTENDER / BOOSTER  
 AUDIO/VIDEO WIRELESS 20-30  
 DVI 20-12  
 HDMI 16-67  
 HDMI OVER CAT5 16-68, 20-25



KVM . . . . .	16-56	FLASH PLAYER TRANSMIT . . . . .	17-42	LEADS [XBOX] . . . . .	15-14	HARD DISK DRIVE . . . . .	16-22
PRINTER 300M [D25] . . . . .	16-113	FLASHING . . . . .		LIGHT [GAME BOY] . . . . .	15-16	ACC . . . . .	16-18
REMOTE CONTROL . . . . .	20-30	DIODE . . . . .	01-22	LINK CABLE GB . . . . .	15-16	HARNESS . . . . .	
USB . . . . .	16-127	LIGHTS [12VDC] . . . . .	18-24	LINK CABLE GBA . . . . .	15-17	CAR . . . . .	07-41
VGA . . . . .	16-55	MOBILE PHONE ITEMS . . . . .	17-34	LINK CABLE PSX . . . . .	15-10	CAR KITS . . . . .	18-52
EXTENSION . . . . .		FLAT BELTS . . . . .	05-03	MEMORY NINTENDO . . . . .	15-18	COMPUTER POWER . . . . .	16-41
ANTENNA TV LEADS . . . . .	08-25	FLAT BLADE SCREWDRIVER . . . . .	14-02	MEMORY CARD PSX . . . . .	15-10	SPEAKER INTERRUPTER . . . . .	18-39
AUDIO/VIDEO LEADS . . . . .	08-10	FLAT WIRE CONNECTS . . . . .	05-09	MEMORY STICK [PSP] . . . . .	15-04	HD15 OVER CAT5 . . . . .	20-25
AUDIO/VIDEO EXTEND . . . . .	20-30	FLOATING GROUND [AUTO] . . . . .	18-36	MOD KITS . . . . .	15-02	HD SET TOP BOX . . . . .	20-02
CAR ACCESSORY LEAD . . . . .	18-31	FLOOR STAND [SPEAKER] . . . . .	06-38	MOTOR [PS] . . . . .	15-11	HDMI . . . . .	
CAR ANTENNA CABLE . . . . .	18-72	FLOOR STAND [SPEAKER] . . . . .	20-44	MULTI-PLAYER [PSX] . . . . .	15-10	ADAPTORS . . . . .	16-121
COMPUTER [KVM] . . . . .	16-56	FLOOR STAND [SPEAKER] . . . . .	20-48	NINTENDO ACC . . . . .	15-18	BOOSTER . . . . .	16-123
COMPUTER [KVM LEADS] . . . . .	16-53	FLOPPY DISK BLANK . . . . .	16-26, 20-38	OUTPUT TO MONITOR . . . . .	15-19	CABLES . . . . .	16-122
COMPUTER LEADS . . . . .	16-110	FLOPPY DISK DRIVE . . . . .	16-14	PISTOLS [PS] . . . . .	15-09	CONVERTERS . . . . .	16-67, 20-13
CORDS [240VAC] . . . . .	12-12	FLOPPY DISK CLEANER . . . . .	16-78	PS USB HDD BACKUP . . . . .	15-07	LEADS . . . . .	16-122
KEYBOARD/MOUSE . . . . .	16-109	FLUORESCENT . . . . .		POWER PS-ONE . . . . .	15-11	OVER CAT5 . . . . .	16-68, 20-25
LEAD SAFETY LOCK . . . . .	12-13	COMPACT, LIGHT [CFL] . . . . .	12-10	POWER PSP . . . . .	15-06	REPEATER . . . . .	16-67
LEADS - AC 240V . . . . .	12-13	CAR WORK LIGHT ACC . . . . .	18-25	POWER SUPPLY PSX/PS2 . . . . .	15-11	SCALER . . . . .	16-70
LEADS - AV . . . . .	08-14, 08-24	INVERTER 12V & 24V . . . . .	12-34	POWER SUPPLY GB . . . . .	15-16	SPLITTER/SWITCHES . . . . .	16-67
LEADS - DVI . . . . .	08-04	FLUSH MOUNT SPEAKERS . . . . .	06-30	POWER SUPPLY XBOX . . . . .	15-14	SPLITTER/SWITCHES . . . . .	20-13
LEADS - HDMI . . . . .	08-09	FLUX [SOLDERING] . . . . .	14-37	REMOTE PS2 FOR DVD . . . . .	15-08	WALL PLATES . . . . .	16-124
LEADS - TV ANTENNA . . . . .	08-25	FLYBACK TRANSFORMERS . . . . .	03-10	RF CONVERTER PS . . . . .	15-10, 15-18	HEAD . . . . .	
LEADS - VGA . . . . .	08-11	FLYWHEEL PHILIPS CASSETTE . . . . .	05-05	RF CONVERTER UNI . . . . .	15-18	AUDIO . . . . .	05-04
MAINS LEAD . . . . .	12-13	FLYWHEEL VCR CAPSTAN . . . . .	04-10	RF CONVERTER XBOX . . . . .	15-14	CLEANING CASS' TAPE . . . . .	05-20
MONITOR CABLE [VGA] . . . . .	16-117	FM FILTER MAST MOUNT . . . . .	09-22	SPARE PARTS [PS] . . . . .	15-11	CLEANING CASS' VCR . . . . .	04-10
MONITOR CABLE [DVI] . . . . .	16-119	FM RADIO EXPAND JAPAN . . . . .	18-36	SPINDLE CD FOR PSX . . . . .	15-11	CLEANING SOLUTION . . . . .	14-67
POWER CORDS - AC 240V . . . . .	12-13	FM VHF UHF SPLITTER BOX . . . . .	09-02	STANDS [PS2] . . . . .	15-09	CLEANING SWABS . . . . .	14-65
TELEPHONE CABLE . . . . .	07-44	FME . . . . .		STARTERS KIT [PS2] . . . . .	15-08	DRUM ASSEMBLY [VCR] . . . . .	04-08
TV FLYLEADS . . . . .	08-25	ADAPTORS . . . . .	07-33, 19-10	STARTERS KIT [PSP] . . . . .	15-04	VCR [A/C] . . . . .	04-09
XBOX CONTROLLER . . . . .	15-14	CABLE & LEADS . . . . .	19-12	STEERING WHEEL . . . . .	15-13	VCR [VIDEO] . . . . .	04-03
[SEE ALSO COMPUTER]		CRIMP & PLUGS . . . . .	07-26, 19-08	STEERING WHEEL [XBOX] . . . . .	15-13	HEAD CLEANER . . . . .	
EXTERNAL . . . . .		FOAM . . . . .		VGA CONVERTER . . . . .	15-19	8 MM . . . . .	04-100, 20-35
FLOPPY DRIVE . . . . .	16-18	CLEANER FOR PLASTICS . . . . .	14-67	WII ACCESSORIES . . . . .	15-03	CASSETTE [AUDIO] . . . . .	05-20
HARD DISK DRIVE . . . . .	16-19	CLEANING SWABS & TIPS . . . . .	14-65	WIRELESS CONTROLLER . . . . .	15-07	CASSETTE [VHS] . . . . .	04-100
MEDIA SERVER BOX . . . . .	16-21	TAPE FOR GROMMETS . . . . .	14-59	X-BOX ACCESSORIES . . . . .	15-12	CHAMOIS & SWABS . . . . .	14-65
STORAGE MEDIA PLAYER . . . . .	20-04	FOCUS [TV] . . . . .		XBOX TO PC . . . . .	15-14	DAT AUDIO . . . . .	05-20, 20-35
EXTRACTOR . . . . .		POT . . . . .	03-02	GAMEBOY ACCESSORIES . . . . .	15-16	DAT COMPUTER . . . . .	16-26
FUME EXHAUST FAN . . . . .	14-35	RESISTORS . . . . .	03-02	GAMEBOY ADVANCE . . . . .	15-17	SOLUTION . . . . .	20-35
TOOL [IC] . . . . .	14-09	FOOT SWITCH . . . . .	02-27	GAMEBOY BATTERIES . . . . .	11-49	SPRAY . . . . .	14-66, 20-35
VIDEO HEAD . . . . .	14-09	FORMAT CONVERT [VIDEO] . . . . .	20-06	GAMEPAD [PS] . . . . .	15-07	TAPE [AUDIO] . . . . .	05-20
		FOUNTEK HI FI . . . . .	06-68, 06-110	GAMEPAD [XBOX] . . . . .	15-12	VHS VCR . . . . .	04-100
		FOXTEL CABLES . . . . .	20-19	GAMESHARK [PS] . . . . .	15-10	VHS-C . . . . .	04-100
		FOXTEL REMOTES . . . . .	09-13, 20-19	GAS DC SURGE ARRESTOR . . . . .	14-25	HEAD EXTRACTOR [VCR] . . . . .	04-98, 14-09
		FOXTEL EXTENDER . . . . .	09-12, 20-30	GASKET TAPE [SPEAKER] . . . . .	06-40	HEADPHONE . . . . .	
		FREEZE SPRAY . . . . .	14-66	GEL [GLUE] . . . . .	14-60	BLUETOOTH . . . . .	06-06, 17-08
		FREQUENCY COUNTER . . . . .	14-45	GENDER CHANGERS . . . . .		COMPUTER . . . . .	06-08
		FRIDGE LAMPS . . . . .	02-22, 10-10	AV . . . . .	07-30	CORDESS . . . . .	06-03, 06-06
		FUME EXTRACTOR . . . . .	14-35	COMPUTER . . . . .	16-108, 16-121	EARBUDS . . . . .	06-07, 17-44
		FUSE . . . . .		OPTICAL . . . . .	08-03	EARPAD . . . . .	06-08
		ATC / ATM / ATS . . . . .	02-24	DVI . . . . .	08-05	GENERAL . . . . .	06-04, 17-42
		AUTOMOTIVE . . . . .	02-23, 18-40	HDMI . . . . .	08-06	INFRARED . . . . .	06-03
		CERAMIC . . . . .	02-23, 10-13	TELEPHONE . . . . .	07-45	MINI . . . . .	06-05
		CIRCUIT PROTECTOR . . . . .	02-24	GENERATOR . . . . .		USB . . . . .	06-08
		CUT OFF . . . . .	02-18	TV & DTV TEST PATTERN . . . . .	14-39	WIRELESS . . . . .	06-03
		GENERAL . . . . .	02-23	GLASS FUSE . . . . .	02-23	HEADS . . . . .	
		HOLDERS . . . . .	02-25	GLASS THRU ANTENNA . . . . .	18-71	AUDIO . . . . .	05-04
		HOLDER [CAR] . . . . .	18-41	GLOBES . . . . .	02-20, 02-22, 10-10	CASSETTE . . . . .	05-04
		HRC . . . . .	02-24	GLOBES . . . . .	14-57, 14-65	VCR [A/C] . . . . .	04-09
		LAMPS . . . . .	02-20	GLUE EPOXY . . . . .	14-60	VCR [VIDEO] . . . . .	04-03
		MICRO . . . . .	02-24	GLUE ULTRA-FAST . . . . .	14-61	HEADSETS . . . . .	06-08, 16-08
		MICROWAVE . . . . .	10-13	GME KINGRAY . . . . .	09-18	HEARING AID BATTERY . . . . .	11-08
		POLYSWITCH . . . . .	02-19	GOOSE NECK . . . . .		HEAT TRANSFER COMPOUND . . . . .	14-61
		PULLER . . . . .	02-23	CRADLE [PDA/PHONE] . . . . .	17-29	HEAT SHRINK TAPE & TUBING . . . . .	13-18
		PICO . . . . .	02-24	LAMP . . . . .	14-22	HEAT SINKS . . . . .	
		REMOVER TOOL . . . . .	14-08	MIRROR . . . . .	14-22	PC [CPU] . . . . .	16-58
		SEMICONDUCTOR . . . . .	02-24	MICROPHONES . . . . .	06-31, 06-33	VGA RAM . . . . .	16-60
		SHATTER PROOF . . . . .	02-24	SCREWDRIVER . . . . .	14-04	HEEL STRAP ANTISTATIC . . . . .	14-57
		THERMAL [CUTOFF] . . . . .	02-18	GPS ACCESSORIES . . . . .	17-12	HELMAR LUBRICANTS . . . . .	14-66
		FUSIBLE RESISTOR . . . . .	02-14	GPS ANTENNA . . . . .	19-02, 17-14	HERBIE CABLE CLIPS . . . . .	13-16
		FUTABA CONNECTOR . . . . .	11-21	GPS BATTERIES . . . . .	11-55	HEX TIP SCREWDRIVER . . . . .	14-03, 14-04
				GREASE . . . . .	14-60, 14-61	HEX KEY SET . . . . .	14-05
				GRILLE . . . . .		HFE TRANSISTOR TEST LEAD . . . . .	14-51
				SPEAKER . . . . .	06-59	HIGH VOLTAGE . . . . .	
				SPEAKER [CAR] . . . . .	18-11	CAPACITOR [MWO] . . . . .	10-14
				SPEAKER [CEILING] . . . . .	06-19	DIODE [MWO] . . . . .	10-09
				SPEAKER CLIPS . . . . .	06-43	FUSE [MWO] . . . . .	10-13
				SPEAKER CLOTH . . . . .	06-43	LEAD . . . . .	03-07
				GROMMETS . . . . .	12-17, 13-15	PROBE . . . . .	10-07, 14-40
				GROUND LOOP ISOLATOR . . . . .	18-36	TRANSFORMER [MWO] . . . . .	10-06
				GSM SIM CARD READER . . . . .	16-14	TRANSFORMER [TV] . . . . .	03-10
				GUITAR . . . . .		TRANSFORMER TESTER . . . . .	03-06
				LEAD . . . . .	08-18	HOBBY BATTERY PACK . . . . .	11-20
				MIC . . . . .	06-29, 06-32	HOLDER . . . . .	
				SPEAKER . . . . .	06-59	BATTERY . . . . .	11-70
				GUNS . . . . .		FUSE . . . . .	02-25
				CABLE TIE . . . . .	14-12	GPS . . . . .	17-29
				DESOLDER . . . . .	14-34	MOBILE PHONE . . . . .	17-29, 18-14
				HOT GLUE . . . . .	14-24	HOLE SAW . . . . .	14-18
				POP RIVET . . . . .	14-12	HOLSTER: MOB. PHONE . . . . .	17-37
				GUTTER MOUNT CB BASE . . . . .	19-16	PDA / GPS . . . . .	17-36
				GYPROCK WALL PLATE . . . . .	09-05	HOME SECURITY . . . . .	21-02
				GYPROCK SAW . . . . .	14-14, 14-18	HOME THEATRE . . . . .	20-01
						SUB-WOOFER AMPS . . . . .	06-37
						SUB-WOOFER AMPS . . . . .	06-109
						SPEAKERS . . . . .	06-09, 06-102
						HOOK UP WIRE . . . . .	13-10
						HORN . . . . .	
						100V SPEAKER . . . . .	06-19
						MID RANGE . . . . .	06-67
						PA SPEAKER . . . . .	06-47
						PUBLIC ADDRESS . . . . .	06-27
						TWEETER . . . . .	06-67
						HOT GLUE GUN . . . . .	14-24
						HOUSING . . . . .	
						CASSETTE [VCR] . . . . .	04-84
						MOBILE PHONE . . . . .	17-39
						HUB [ETHERNET] . . . . .	16-82
						HUB [USB] . . . . .	16-126
						HUMIDITY SENSOR [MWO] . . . . .	10-12
						HV PROBE . . . . .	03-08, 14-40



## I

IC	
COMPONENT LISTING	01-08
EXTRACTOR	14-09
PANASONIC VCR	04-97
PINS	01-19
SOCKETS	01-19
TOOLS	01-16, 14-09
IBM 3179 HV LEAD	03-07
IDC CABLE	13-13
IDC & IDE LEAD	16-43
IDC & IDE PLUGS DYI	16-105
IDLER	
TYRE [AUDIO]	05-05
TYRE [VCR]	04-25
VCR	04-34
IEC POWER LEADS & PLUGS	12-12
IEEE1394	
ADAPTORS	16-125
EXTERNAL HDD	16-14
IPOD ADAPTOR	16-129
LEADS	16-125
PCI & PCIe CARD	16-48
PCMCIA CARD	16-46
IGNITION NOISE FILTER [AUTO]	18-30
ILLUMINATED MAGNIFIER	14-22
IMPACT WRENCH CAR	18-51
INDOOR ANTENNA	09-08
INDUCTION MICROPHONE	06-29
INDUCTOR	
COMPONENTS	02-13
CROSSOVER	02-13, 06-42
MAGNETIC CORE - TV	03-03
SPEAKER	06-45
INDUSTRIAL NICD & NiMH	11-14
INFRA-RED	
DIODE - REMOTE CONTROL	01-22
DIODE - VCR	04-96
EXTENDER - REMOTES	20-26
EXTENDER - REMOTES	20-30
HEADPHONES	06-03
RECEIVE / TRANSMIT	20-27
REMOTE CONTROLS	20-15
REPEATER	09-14, 20-26
KITS	20-26
SENSORS [VCR]	04-96
INNER DOOR LINING [MWO]	10-11
INSTRUMENT LEADS	08-18
INSTRUMENTAL SPEAKER	06-56
INSTRUMENTAL SPEAKER	06-66
INSULATED SCREWDRIVER	14-02
INSULATION	
METER TESTER MEGA-OHM	14-47
PIERCING PROBE	14-52
TAPE	14-58
WASHERS [IC]	01-18
INTERCOM [VIDEO]	21-02
INTERCOM [WIRELESS]	21-04
INTEGRATED CIRCUITS	01-08
INVERTER	
12V TO 240V	12-33, 18-33
12V TO MULTI DC	12-32, 18-30
12V TO FLUORESCENT	12-34
IP CAMERAS	16-11
IPOD	
ACCESSORIES	16-129, 17-40
ADAPTORS AUDIO OUT	17-40
ADAPTORS POWER	17-41
ADAPTORS VIDEO OUT	16-121
BATTERY REPLACEMENT	11-50
CABLES & LEADS	17-40
CAR CHARGER	17-41
CAR KIT	18-37
CASES & COVERS	17-43
CHARGERS	17-42
LEADS	16-121, 17-40
TRANSMITTERS	17-42
VIDEO LEADS	16-121
IR [SEE INFRA RED]	
IRDA	16-14, 17-17
IRON	
PARTS	14-28
SOLDERING TOOLS	14-24
STANDS & HOLDERS	14-36
ISO CONNECTS [AUTO]	18-52
ISOLATION TRANSFORMER	14-40
ISOLATOR	
CAR BATTERY	12-34
CAR GROUND LOOP	18-36
MAINS	14-40
ISOPROPANOL CLEANING FLUID	14-66

## J

JACKS / PLUGS	07-04, 07-12, 07-16
JAPAN FM EXPANDER	18-36
JEWEL CASE CD & DVD	05-21
JEWELER SCREWDRIVER	14-07
JIGSAW BLADES	14-70
JOINER [SEE PLUGS]	
JOYSTICK	
COMPUTER PC	16-07
COMPUTER LEAD	16-116
GAMEPAD	16-07
PLAYSTATION	15-07
XBOX	15-12
JR CONNECTORS	11-21
JTS BRAND MICROPHONES	06-32
JUMPER CONNECTOR [PCB]	16-42
JUMPER LEADS ALLIGATOR	14-51
JUNCTION BOX 240VAC	12-17

## K

KEY SWITCH	21-27
KEYBOARD	
COMPUTER	16-04
CONTROLLER	21-11, 21-27
EXTENDER OVER CAT5	16-56
KVM	16-51
LEADS - PC	16-109
SECURITY	21-27
SWITCH BOXES	16-52
KEYPAD	
ENTRY [SECURITY]	21-27
GAMEPAD ADDON	16-07
MOBILE PHONE	17-39
NUMERIC [PC]	16-03
REPAIR KIT	14-60
KEYSTONE FOR ANTENNA	09-06
KEYSTONE FOR PC	16-102
KICK SWITCH	02-27
KINGRAY	09-18
KITS [CAMERA & MONITOR]	21-02
KNIFE [BOX CUTTERS]	14-13
KNOB	
ASSORTED	02-32
CHICKEN HEAD	02-32
JVC VCR BUTTON	04-97
TEMPEST & PALSONIC	03-08
KRONE -TYPE IDC TOOL	14-13
KVM ENTERPRISE	16-51
KVM EXTENDER OVER CAT5	16-56
KVM LEADS	16-53, 16-117
KVM SERVER ETHERNET	16-84
KVM SWITCH	16-52

## L

LABELS [TAMPER PROOF]	14-60
LAMP BALLAST [SAMSUNG]	03-09
LAMP BATTEN HOLDER	12-14
LAMPS	
BICYCLE	12-37
FRIDGE	02-22, 10-10
GENERAL	02-22
LED TORCHES	12-36
MICROWAVE	10-10
MINERS	12-37
PATHWAY LIGHTS	12-11
SAMSUNG & SONY	03-09
SEWING MACHINE	02-22, 10-10
QUARTZ HALOGEN	12-11
VCR SENSOR	04-96
LAN [SEE COMPUTER]	
LANTERN BATTERY	11-04, 11-15
LAPEL MIC	06-29
LAPTOP & NOTEBOOK	
ACCESSORIES	16-30
BATTERY	11-56
CARRY CASES	16-30
POWER PACKS	12-29, 16-32
STAND & SECURITY	16-33
LASER	
ALIGNMENT DISKS	05-19
CD & DVD	05-10
CONNECTOR MEMBRANE	05-09
GAME CONSOLE [PS]	15-11
GAME CONSOLE [XBOX]	15-14
LENS CLEANER	05-18
POINTER WITH PC REMOTE	16-07
LCD	
BACK LIGHT TESTER	03-18
INVERTOR BOARDS	03-18
MONITORS	21-09
MONITORS [CAR]	18-20, 21-09
MONITORS [CAR]	21-22
MOUNT BRACKETS [AUTO]	18-18
REVERSING MONITORS	18-22
SCREEN CLEAN	14-62
SCREEN MOUNTING	20-39
LCD & LDP PROJECTOR	
BALLAST	03-09
LAMPS	03-09
LEAD ACID BATTERY	11-28

LEAD LAMPS	02-21
LEADS	08-02
3G	17-28
75 OHM [TV]	08-25
9V BATTERY SNAP	11-70
AC POWER	12-12
AMPHENOL	08-19
ANTENNA [AUTO]	18-72
ANTENNA [NEXT-G / 3G]	16-93
ANTENNA [TV]	08-25
ANTENNA [WIFI]	16-91
BNC	08-24
CAMERA BREAKOUT	08-22
CAR ANTENNA	18-72
CB	19-14
CDMA	17-18, 17-28
COMMUNICATION	19-12
COMPONENT VIDEO	08-20
COMPUTER APPLE	16-112
COMPUTER ETHERNET	16-99
COMPUTER FIBRE OPTIC	16-85
COMPUTER KVM	16-53
COMPUTER MONITOR	16-117
COMPUTER MOUSE & KB	16-109
COMPUTER PERIPHERAL	16-113
COMPUTER POWER	16-42
COMPUTER PRINTER SERIAL	16-113
COMPUTER SCSI	16-110
COMPUTER USB	16-127
COMPUTER WIFI	16-91
DIGITAL AUDIO	08-02, 08-12
DIGITAL CAMERA	08-23
DIN LEADS	08-17
DVC	08-22
DVI	08-04, 16-119
DVI-A TO VGA	16-118
EHT	03-07
EXTENSION AC POWER	12-13
FIBRE OPTIC AUDIO	08-02
FIBRE OPTIC NETWORK	16-85
FIREWIRE	16-125
FME	19-12
GAMEBOY	15-16
HDMI	08-08, 16-122
HIGH QUALITY AV & DIGITAL	08-12
HIGH VOLTAGE TV	03-07
JUMPER [ALLIGATOR]	14-51
KVM	16-53
LUCENT	07-37
MD7P BREAK OUT	08-06
MIDI	16-116
MUSICAL INSTRUMENT	08-18
N	19-12
NINTENDO	15-18
OFC RCA	08-14
OPTICAL FIBRE	08-02
OSCILLOSCOPE PROBES	14-50
PAL LEADS	08-24
PL259 LEADS	08-24
PLAYSTATION	15-10
PLAYSTATION PSP	15-06
POWER	12-12
PS2 TO PC	16-109
RCA LEADS	08-02, 08-12, 08-14
RGB LEAD	08-10, 08-15
S-VIDEO	08-21
SCART LEAD	08-10, 08-13
SMA	19-12
TEST METER	14-50
TOSLINK	08-02, 08-13
TV COAX FLYLEADS	08-25
VIDEO CAMERA	08-22
VIDEO DUB KIT	08-24
XBOX	15-14
XBOX TO PC	16-07
WIFI	16-91
WII	15-03
LEAKAGE TEST [MW OVEN]	10-07
LEARNING REMOTES	20-18
LEATHER	
PHONE CASES	17-36
LED	01-22
FLASHING	01-22
IR EMITTER	01-22
LIGHT STRIPS	18-24
MOBILE PHONE	17-34
PANEL CLIPS & BEZELS	01-23
SUPER BRIGHT	01-23
TORCHES	12-36
TRI-COLOURED	01-22
VCR	04-96
LENS CLEANER [CAMERA]	14-63
LENS CLEANER [LASER]	05-18
LIGHT	
DIMMER	12-16
GAMEBOY	15-16
GLOBES [APPLIANCE]	02-22
GLOBES [ASSORTED]	02-20
NIGHT	12-11
MICROWAVE	10-10
PATHWAY [240VAC]	12-11
QUARTZ HALOGEN	12-11
SCRIBE DVD-R DISKS	20-36
STICKS & STRIPS [12V]	18-24
TIMERS [MAINS POWER]	12-08
TORCHES	12-36
VCR	04-96
LIGHTNING ARRESTER "N"	19-17
LINE FILTER - POWERWARE	12-04
LINE OUTPUT TRANSFORMER	03-10

LINE TRANSFORMER	
SPEAKER	06-19
LINX AV DISTRIBUTION	20-28
LINX IR & RF DISTRIBUTION	20-26
LITHIUM BATTERY	11-05
LOADING BELTS [CD & DVD]	05-02
LOADING BELTS [VCR]	04-24
LOCKS	
CABLE & PADLOCK	16-33, 21-28
CAM	21-27
COMBINATION & PAD	16-33
KEY SWITCH	21-27
LOCKING	
CATCH TV & VCR DOOR	02-29
PAINT [SCREWS]	14-60
LOCTITE GLUE	14-61
LOGIC PROBE	14-48
LOGIC PULSER	14-48
LONG NOSE PLIERS	14-16
LOOK-C INTERCOMS	21-02
LOOP ISOLATOR [GROUND]	18-36
LOPT	
COMPUTER MONITOR	03-17
DIEMEN MANUAL	03-08
TELEVISION	03-10
TESTER	03-06, 14-40
LOUDSPEAKERS [SEE SECTION 06]	
LUBRICANTS SERVICE AIDS	14-66
LUCENT ADAPTOR LEAD	07-37
LUMINANCE DELAY LINE TV	03-02
LVD SCSI LEAD	16-111
M	
MAGNETIC	
BASE CB/UHF	19-16
GPS ANTENNA	19-02
PHONO CARTRIDGE	05-23
MAGNETIC SHIELDED SPEAKER	
COMPUTER	16-09
DAI-ICHI	06-54
DESKTOP	06-09
PAE / LOGIC	06-88
SCAN SPEAK	06-74
TV	06-49
VIFA	06-83
MAGNETRON [MWO]	10-02
MAGNIFYING GLASSES	14-22
MAGNIFYING LAMPS	14-23
MAINS 240VAC	12-02
AC ADAPTORS	12-22
ADAPTOR PLUGS INTERNTL	12-19
APPLIANCE TESTER	14-42
CABLE	13-12
CAPACITORS	02-07
CORDS	12-12
DOUBLE ADAPTOR	12-11
FINDER	12-17
INVERTORS	12-33
ISOLATION TRANSFORMER	12-21
JUNCTION BOX	12-17
LEADS	12-12
LIGHT DIMMER	12-16
NIGHT LIGHTS [INDOOR]	12-11
PLUGPACKS	12-22
PLUGS & SOCKETS	12-14
POWER BOARD	12-04
POWER POINTS	12-16
POWER SUPPLIES 13.8V	12-29
POWERWARE PROTECT	12-02
RCD POWERBOARD	12-08
RCD SWITCH	12-09
SAFETY SCREWDRIVER	12-18
SAFETY PLUG	12-15
STEP DOWN 110VAC	12-19
SURGE PROTECTOR	12-09
SWITCHES	12-16
TIMER	12-08
TRANSFORMERS	12-20
VARIAC	12-21, 14-40
UPS	12-02
MANGANESE BATTERY	11-02
MANUALS	10-07, 14-54, 18-39, 21-04
MARINE	
ANTENNA	19-20
ANTENNA MOUNT BASE	19-17
COMMUNICATION	19-04
RADIO HOUSING / FACIA	19-06
SPEAKER	06-50, 19-06
MARSHAL TRANSFORMERS	01-28
MASKING TAPE	14-58, 18-47
MASONRY DRILL BITS	14-18
MASTHEAD	
AMPLIFIER BOOSTER	09-19
BALUN	09-03
MD7P BREAK OUT	08-06
MECHANISM	
CD & DVD LASER	05-10
VCR FRONT LOAD	04-82
VCR REEL & LOAD	04-34
MEDIA	
8MM VIDEO CASSETTE	20-34
ANSWERING TAPE	05-20
AUDIO CASSETTE TAPE	05-20
AUDIO CASSETTE TAPE	20-35
BLUE RAY BLANK DISKS	20-37
CAMERA CASSETTES	20-34
CASES	16-28



CD / CDRW	05-20, 16-26, 20-38
DAT	05-20, 16-26, 20-35
DVD	16-24, 20-36
FLOPPY DISK	16-26, 20-38
LABELLING	16-35
MICRO-CASSETTE	05-20, 20-35
MINI CDR	20-38
MINI DISK	05-20, 16-25, 20-37
MINI DV	20-34
S-VHS CASSETTES	20-34
STORAGE SOLUTIONS	16-28
VHS & VHS-C CASSETTES	20-34
MEDIA CENTRE REMOTES	20-15
MEDIA PLAYER BATTERIES	11-51
MEGA-OHM METER	14-47
MEMBRANE CONNECTOR	05-09
MEMORY BATTERIES	11-08, 11-18
MEMORY CARDS & STICKS	16-27
CF, MMC, MS, SD, XD	16-27
NINTENDO	15-18
PLAYSTATION PS-1 & PS2	15-10
PLAYSTATION STICK PSP	15-04
READER [USB]	16-14
USB FLASH DRIVE	16-26
MEMORY STICK	16-26
MERCURY BATTERY	11-07
METAL SCREWS	14-68
METERS	
12V BATTERY MONITOR	11-21
ANALOGUE	14-47
APPLIANCE TEST	14-42
CASE	14-49
CAPACITANCE	14-47
CAT5 ETHERNET LAN TEST	16-81
CLAMP [CURRENT]	14-45
CRT TEST	14-40
DIGITAL	14-44
EMF	14-48
FIELD STRENGTH [RF]	14-41
FREQUENCY COUNTER	14-45
HIGH VOLTAGE PROBE	14-40
INDUCTANCE	14-47
INSULATION	14-47
LEADS	14-50
LOPT TV [HORIZ-TX]	14-40
MEGA-OHM	14-47
MICROWAVE LEAK	14-48
PEN DIGITAL	14-43
PICTURE TUBE TESTER	14-40
PROBES	14-52
REMOTE CONTROL TEST	20-18
RS232 COMPUTER	14-46
SATELLITE FINDER	14-41
SOUND LEVEL	14-43
THERMOMETER	14-48
VSWR & POWER	19-17
MICA WASHERS	01-18
MICRO	
CASSETTE	05-20, 20-35
FIBRE CLEANING CLOTHS	14-63
FUSE	02-24
PROCESSORS [IC]	01-08
SWITCH	02-27
TIPS [CLEANING]	14-65
MICROPHONE	
ADAPTORS	07-30
AMPHENOL / CANNON	07-09
BODY PACKS	06-34
CABLE SHIELDED	13-03
CABLE TESTER	06-23
CARDIOID	06-30
CARRY CASE	06-33
CASSETTE	06-29
CB RADIO	19-04
CELLULAR PHONE	06-29
CHOIR	06-33
COMMS [AMATEUR / CB]	19-04
COMPUTER	16-10
CONDENSER INSERT	06-29
CURLY CORD	19-04
DESK STAND	06-29
DRUM	06-31
DUAL IMPEDANCE	06-30
DYNAMIC	06-29
FM WIRELESS	06-31
GOOSENECK	06-31
GOOSENECK [VOCAL]	06-33
GROUND LOOP STOP	06-23
GUITAR [PICK UP]	06-29
HANDS FREE	17-06
HEADSET TYPE	06-27, 06-31
HOLDER	06-28, 06-33
HOLDER [CB]	19-04
INDUCTION	06-29
INSERTS	06-29
INSERTS [CB]	19-04
INSTRUMENT	06-31
JTS	06-32
KICK DRUM	06-31
LAPEL	06-29
LEADS	06-28, 06-32
LEADS	08-18
LEVEL CONVERTER	06-23
MOBILE PHONE	17-06
NEUTRIK	07-07
PHANTOM POWER BOX	06-23
PLUGS	07-04, 07-17
PRE-AMP	06-23
PROFESSIONAL	06-30
SPLITTER	06-23

STANDS	06-28
STEREO LAPEL	06-29
TRANSMITTER	06-34
VOCAL	06-36
WEBCASTING	16-10
WIND SCREENS	06-29
WIRELESS FM MIC	06-31
WIRELESS SYSTEMS	06-34
MICRO-TEMP FUSES	02-24
MICROWAVE	10-02
APPLIANCE TEST	10-12, 14-42
BELTS	10-14
CAPACITORS	10-14
CAROUSEL MOTOR	10-13
DIODES & HV PROTECT	10-09
DOOR LINING	10-07, 10-11
DOOR SWITCHES	10-08
FIXING NUTS [MAGNETRON]	10-07
FUSES	10-13
GLASS TRAY	10-12
GLOBES & LAMPS	10-10
HUMIDITY SENSOR [PANAL]	10-12
LEAKAGE TESTER	10-07, 14-48
LINER	10-11
MAGNETRON	10-02
MANUAL & INFO	10-07, 10-14
MOTORS	10-13
NEON TESTER	10-07
NUTS [MAGNETRON]	10-07
OVEN & DOOR SWITCH	10-08
PAINT [TOUCH UP]	10-08
PANASONIC SMPS KIT	10-06
POWER TRANSFORMER	10-06
ROOF LINER COVER	10-11
SENSOR [HUMIDITY]	10-12
TAMPER PROOF LABEL	10-07
TESTING	10-07
THERMAL CUT	10-12
THERMISTOR	10-12
TRANSFORMER [MAIN]	10-06
TRAY CARRIER	10-12
TRAY COUPLER	10-12
VARIATOR	10-12
MIDI LEADS	16-116
MIDRANGE SPEAKERS	
DAI-CHI	06-52
PEERLESS	06-91
SCAN SPEAK	06-76
SCANDINAVIAN ACOUSTICS	06-70
VIFA	06-82
MINERS LAMP	12-37
MINI CDR DISK	20-38
MINI DISK	
RACK	05-21
RECORDABLE	05-20, 20-37
STORAGE	05-21
MINI DV CASSETTES	20-34
MIRROR - DENTIST TYPE	14-22
MIRROR - ON A GOOSE NECK	14-22
MIXER	
AUDIO	05-22, 06-22
VIDEO	20-05
MOBILE PHONE	
ACCESSORIES	17-02, 17-29
ADAPTORS	17-19, 19-10
ANTENNA	17-14, 17-22, 18-70
ANTENNA [COVERT MOUNT]	17-14
ANTENNA [DIRECTIONAL]	17-27
ANTENNA [GLASS MOUNT]	17-15
ANTENNA LEADS	17-18
ANTENNA MOUNTS	17-25
BATTERY	11-54, 17-03
BLUETOOTH ACCESSORIES	17-08
BRACKETS [CAR]	17-31, 18-15
BULL BAR BRACKET	19-16
CABLE	17-21
CAR CHARGER	17-03
CAR KIT	17-05
CAR MAX	17-03
CAR MOUNTING	17-29, 18-14
CAR STEREO INTEGRATE	17-06
CASE LEATHER & CLEAR	17-36
CASE LONSDALE	17-37
CASE SCALA	17-37
CHARGERS	17-03
COMPUTER CONNECT	17-16
CONNECTOR PLUGS	17-19
COVERS	17-36
CRADLES & HOLDERS	17-29
DA-SACK BUM BAG	17-02
DATA CABLE FOR PC	17-17
DATA SUITE	17-17
DISMANTLING TOOLS	17-39
DISPLAY STAND [SALE]	17-35
DRIVESAFE	17-07
EMERGENCY CHARGER	17-03
FLASHING ACCESSORIES	17-34
FONE DATA SUITE	17-17
GLASS THRU ANTENNA	17-22
GSM SIM CARD READER	17-16
HAND STRAP	17-35
HANDSFREE BLUETOOTH	17-09
HANDSFREE CAR KIT	17-07
HANDSFREE PERSONAL	17-02
HANDSFREE PLUG&GO	17-06
HOLDER [CAR]	18-14
HOLDERS [CAR]	17-29
HOLSTER CELLINK	17-36
HOUSINGS COVERS	17-39
KEYPAD [REPLACEMENT]	17-39

LCD SPARE PARTS	17-39
LEATHER CASE	17-36
MICROPHONE	06-29, 17-06
MINI HANDS FREE	17-02
MOUNT BRACKETS [CAR]	17-31
MOUNT BRACKETS [CAR]	18-15
PARTS	17-39
PATCH CABLE [ANT]	17-18
PLUG'N'GO	17-06
PLUGS	17-20
SIM CARD BACKUP	17-39
SIM CARD READER [USB]	17-16
SPEAKERS	17-39
SPEAKER	17-05
STARTER PACKS	17-02
TRAVEL CHARGER	17-03
UPGRADE KITS	17-05
USB CHARGER	16-17, 17-03
USB CHARGER	17-41
USB DATA CABLE	17-13, 17-17
MOD KITS	
GAME [PS & XBOX]	15-02
PANASONIC MICROWAVE	10-06
TV	03-07
VCR	04-31, 04-97
MODE 3 PHONE ADAPTOR	07-44
MODEM	
ADAPTORS FOR PHONE	07-44
ADAPTORS OVERSEAS	12-19
ADSL	16-89, 16-95
DIAL UP	16-49
LEADS [ETHERNET]	16-99
LEADS [RS232]	16-114
LEADS [NULL-MODEM]	16-114
LEADS [USB]	16-127
SURGE PROTECTOR	12-04
MODULAR	
ADAPTOR [PC]	16-98
ADAPTOR [TELEPHONE]	07-44
CABLE [PHONE]	07-44, 16-98
GENDER CHANGERS	07-44, 16-98
PLUGS & BOOTS RJ45	16-100
TOOL	14-12
MODULATOR RF	09-13, 20-32
MONITOR	
12V BATTERY	11-21
CCTV	21-07
DOOR PHONE	21-02
DVR	21-32
GENERATOR TESTER	14-39
LCD - CAR	18-20
LCD - CAMERA TESTER	21-09
LEADS	16-117
LOPT	03-17
MOUNTING	20-39
REVERSING [CAR]	18-22
SELECTOR	16-56, 21-10
SPLITTER	16-55, 21-08
SUPPORT STANDS	16-34, 20-39
SWITCH & KVM	16-51
TEST PATTERN GENERATE	16-76
TEST PATTERN TV	14-39
MOTOR	
CASSETTE	05-06
CD & DVD	05-08
DUBBING [DUAL SPEED]	05-07
MICROWAVE	10-13
START CAPACITORS	02-07
VCR	04-10
MOUNTING BLOCK 240V	12-16
MOUNTING CAMERAS	21-16, 21-26
MOUSE	
COMPUTER	16-02
LEADS	16-109, 16-115
MP3 PLAYER ACCESSORIES	17-40
MULTIMEDIA	
HEADSETS	06-08, 16-08
MICROPHONE	06-08
SPEAKER	06-09, 16-09
STORAGE	16-21, 16-27
MULTIMETER	14-44
MULTIMETER LEADS	14-50
MULTI-PLAYER LINK CABLE GB	15-17
MULTI-PLAYER LINK CABLE PS	15-10

## N

N CONNECTOR	07-34
N PLUGS & SOCKETS	07-25
NEEDLE FILES	14-08
NEEDLES [STYLUS]	05-25
NEON LAMPS	02-20
NEON LIGHT STICKS	18-24
NETWORK [SEE COMPUTER]	
NEUTRIK NEXUS CONNECT	07-06
NEXT G ANTENNA WHIP	19-19
NICAD BATTERIES	11-12
NIGHT LIGHTS	12-11
NIMH BATTERIES	11-12
NINTENDO ACCESSORIES	15-18
NINTENDO BATTERIES	11-49
NINTENDO WII ACCESSORIES	15-03
NIPPER PLIER	14-14
NITRILE GLOVES	14-57
NOISE FILTER / SUPPRESSOR	
CAR AUDIO	18-30
COMMUNICATION	19-07
MAINS [240V/AC]	12-04
NON INDUCTIVE RESISTOR	02-14
NOTEBOOK & LAPTOP	
ACCESSORIES	16-30
BATTERY	11-56
CARRY CASES	16-30
POWER PACKS	12-28, 16-32
STANDS	16-33
NTSC TO PAL CONVERTER	20-08
NUMERIC KEYPADS	16-03
NUTS	
COMPONENT MOUNT	01-18
MAGNETRON	10-07
NUTS & BOLTS	14-69
NYLON BOLTS & WASHERS	01-18

## O

OCTAL VALVE BASES	01-28
OFC [OXYGEN FREE CABLE]	
CABLE	13-02
LEADS	08-12, 08-14
OFFICE WIPES	14-62
OIL PEN	14-60
OMB TV SUPPORTS	20-39
OPTIC FIBRE [SEE FIBRE OPTIC]	
OPTICAL	
AUDIO CONVERTER	05-22, 08-03
CABLE SELECTOR	08-03, 09-16
FIBRE NETWORK [PC]	16-85
LEADS	08-02
OPTO COUPLER	
IC	01-23
VCR	04-96
ORNAMENTAL LEADS	18-25
OSCILLOSCOPE	
LEADS / PROBE	14-50
OUTDOOR	
ANTENNA ROTATOR	09-15
CAMERA HOUSINGS	21-20
CAMERAS [SECURITY]	21-16
SPEAKER	06-11
SPEAKER ENCLOSURE	06-46
OVERCOAT PEN [PAINT]	14-60
OVERSEAS ADAPTOR	12-19



## P

PA AMPLIFIER . . . . .	06-22
HORN SPEAKER . . . . .	06-19, 06-47
SPEAKER . . . . .	06-27
SYSTEM . . . . .	06-26
PABX MUSIC ON HOLD . . . . .	07-46
PACKAGING TAPE . . . . .	14-58
PACK DIODE . . . . .	01-20
PAD . . . . .	
GAME . . . . .	15-07, 15-12, 16-07
LOCK SECURITY CABLE . . . . .	21-28
MOUSE . . . . .	16-02
PAE SPEAKERS . . . . .	06-88
PAINT . . . . .	
BRUSHES . . . . .	14-17
LOCKING . . . . .	14-60
MICROWAVE TOUCH UP . . . . .	10-07
SILVER-CONDUCTIVE . . . . .	14-60
TAMPER . . . . .	14-60
PAL . . . . .	
ANTENNA ACCESSORIES . . . . .	09-02
ANTENNA LEADS . . . . .	08-25
GENERATOR . . . . .	14-39
TO NTSC CONVERTER . . . . .	20-08
PALM PC BATTERIES . . . . .	11-52
PAN & TILT . . . . .	21-11, 21-19
PANASONIC SLA BATTERY . . . . .	11-29
PANASONIC MWO INVERT KIT . . . . .	10-06
PANEL HOLE CUTTERS . . . . .	14-18
PANEL MOUNT . . . . .	
CIRCUIT BREAKER . . . . .	12-16
FUSE HOLDER . . . . .	02-25
SOCKETS . . . . .	07-06
PATCH LEADS . . . . .	
AV . . . . .	08-10
CAR ANTENNA . . . . .	18-72
CELLULAR . . . . .	17-18, 19-12
COMPUTER PERIPHERAL . . . . .	16-112
ETHERNET . . . . .	16-99
NEXT-G / 3G . . . . .	16-93
TELEPHONE . . . . .	07-44
WIFI . . . . .	16-91
PATHWAY LIGHTS INDOOR . . . . .	12-11
PATTERN GENERATOR . . . . .	
HDTV / DVI / VGA . . . . .	03-05, 16-76
TV / VIDEO . . . . .	03-05, 14-39
PC ACCESSORIES . . . . .	16-02
SEE COMPUTER . . . . .	
PSP ADAPTOR . . . . .	15-06
XBOX ADAPTOR . . . . .	15-14
PCB . . . . .	
BATTERIES . . . . .	11-09, 11-18
CLEANING BRUSHES . . . . .	14-64
CLEANING PEN . . . . .	14-64
COLOUR [VCR] . . . . .	04-97
COMPUTER . . . . .	16-46
HOLDER STAND . . . . .	14-23
PROTOTYPE . . . . .	01-17
SPRAYS . . . . .	14-67
PCI CARD . . . . .	16-48
PCMCIA . . . . .	16-46
PDA BATTERIES . . . . .	11-52
PDA USB CABLE . . . . .	16-127, 17-13
PEARL CATCHER . . . . .	14-09
PEERLESS SPEAKER . . . . .	06-90, 18-02
PEERLESS KIT . . . . .	06-102
PEN . . . . .	
CONDUCTIVE . . . . .	14-60
FIBRE PCB CLEANING . . . . .	14-63
OIL . . . . .	14-60
PROTECTIVE PAINT . . . . .	14-60
PEPI THERMAL SWITCH . . . . .	02-18
PERSONAL HANDS FREE . . . . .	17-02
PHANTOM POWER [MIC] . . . . .	06-23
PHILIPS . . . . .	
BACKUP BATTERY . . . . .	11-19
FLYWHEEL [CAR AUDIO] . . . . .	05-05
SCREWDRIVER . . . . .	14-02
SWITCHES . . . . .	02-29
VCR PARTS . . . . .	See Section 4
PHONE ACCESSORIES . . . . .	07-44
PHONE CABLE . . . . .	13-12
PHONE [MOBILE] . . . . .	17-02
PHONO . . . . .	
ANTI-STATIC SPRAY . . . . .	14-67
BELTS . . . . .	05-03
CARTRIDGE . . . . .	05-23
INPUT CONVERTER . . . . .	05-22
INPUT PREAMP . . . . .	05-22
LEADS . . . . .	08-18
LINE CONVERTER . . . . .	05-22
PLUGS . . . . .	07-04, 07-07, 07-14, 07-18
RECORD CLEANING . . . . .	05-24
STYLUS . . . . .	05-25
WATER LEVEL GAUGE . . . . .	05-24
WIRES [FOR CARTRIDGE] . . . . .	05-24
PHOTO . . . . .	
DIODE [VCR] . . . . .	04-96
INTERRUPTER [VCR] . . . . .	04-96
IR DIODE . . . . .	01-22
OPTO COUPLERS . . . . .	01-24
POSITIVE RESIST CAN . . . . .	14-67
TRANSISTOR . . . . .	01-22, 01-23
PICO FUSE . . . . .	02-24
PICTURE TUBE . . . . .	
REJUVENATOR . . . . .	14-40

SOCKET . . . . .	03-04
PIEZO . . . . .	
BUZZER . . . . .	06-46
ELEMENT . . . . .	06-46
PIG TAIL [CAR RADIO ANT] . . . . .	07-40
PILOT LAMPS . . . . .	02-20
PILOT SUPERTEL REMOTE . . . . .	20-20
PINCH ROLLER . . . . .	
AUDIO CASSETTE . . . . .	05-05
VCR . . . . .	04-26
PIR [SECURITY] . . . . .	21-07, 21-19, 21-29
PISTOL . . . . .	
DESOLDERING . . . . .	14-34
GAME CONSOLE PSX . . . . .	15-09
GAME PSX RELOAD PEDAL . . . . .	15-09
PL259 LEADS . . . . .	08-24
PL259 & SO239 . . . . .	07-27
PL259 & SO239 ADAPTORS . . . . .	07-37
PLASMA SCREEN CLEAN . . . . .	14-62
PLASMA SCREEN MOUNTING . . . . .	20-39
PLASTIC BAGS . . . . .	01-16
PLASTICS LUBE GREASE . . . . .	14-61
PLAYSTATION ACCESSORIES . . . . .	15-04
PLCC IC EXTRACTOR . . . . .	14-09
PLIERS . . . . .	14-16
PLUG'N'GO [CELL PHONE] . . . . .	17-06
PLUG PACK POWER . . . . .	12-22
PLUGS . . . . .	07-02
ADAPTERS REFERENCE . . . . .	07-28
AMPHENOL - ALCATEL . . . . .	07-09
ANTENNA [F & PAL] . . . . .	07-23
ANTENNA AUTOMOTIVE . . . . .	07-40
APPLIANCE 240VAC . . . . .	12-15
AUDIO . . . . .	07-02
BANANA . . . . .	07-04
BATTERY . . . . .	11-21, 11-70, 18-42
BETA CAMERA . . . . .	07-18
BNC . . . . .	07-22
BNC & TNC PINS . . . . .	07-27
BULLET . . . . .	07-43
CABLE TERMINATORS . . . . .	07-05
CANNON . . . . .	07-09
CAR ANTENNA . . . . .	07-40
CAR HARNESS . . . . .	07-41
CAR QUICK DISCONNECT . . . . .	07-41
CB MICROPHONE . . . . .	07-40
CIGARETTE LIGHTER . . . . .	07-21
COAXIAL [TV ANTENNA] . . . . .	07-23
COMMUNICATION . . . . .	07-25, 19-08
COMPUTER . . . . .	16-98, 16-100, 16-105
DC . . . . .	07-20
DEANS 1300 . . . . .	11-21
DIN . . . . .	07-13, 07-18
EIAJ . . . . .	07-21
END CAPS . . . . .	07-37
ETHERNET . . . . .	16-100
F TYPE . . . . .	07-24
FME . . . . .	07-26
FUTABA CONNECTORS . . . . .	11-21
HARNESS [CAR] . . . . .	07-41
IDC FLAT RIBBON . . . . .	16-105
IEC 240VAC MAINS . . . . .	12-14
JR CONNECTORS . . . . .	11-21
LUCENT . . . . .	07-26
M259 MINI UHF . . . . .	07-27
MCX MINI UHF . . . . .	07-26
MICROPHONE . . . . .	07-08
MICROPHONE [CB] . . . . .	07-40, 19-04
MODULAR . . . . .	07-45, 16-100
NEUTRIK . . . . .	07-06
N TYPE . . . . .	07-25
PCB EDGE . . . . .	16-105
PROFESSIONAL AUDIO . . . . .	07-02
PL259 . . . . .	07-27
POWER 240VAC . . . . .	12-15
QUICK DISCONNECT . . . . .	07-41
RCA [GOLD] . . . . .	07-02, 07-14
RF . . . . .	07-22
RJ45 [NETWORKING] . . . . .	16-100
S-VIDEO . . . . .	07-15
SCART . . . . .	07-18
SMA & SMB . . . . .	07-25
SPADE . . . . .	07-18, 07-43
SPEAKON CONNECT . . . . .	07-06
TAMIYA . . . . .	11-21
TELEPHONE . . . . .	07-44
TERMINAL BLOCK . . . . .	07-42
TERMINATOR BNC . . . . .	07-22
TERMINATOR . . . . .	07-05
TNC . . . . .	07-26
TV ANTENNA . . . . .	07-23
VIDEO CAMERA . . . . .	07-18
WALL MOUNT . . . . .	07-38
POS DISPLAY STAND [MOB] . . . . .	17-35
POLYESTER CAPS . . . . .	02-06
POLYPROPYLENE CAPS . . . . .	02-04
POLYGLIDE PLASTIC LUBE . . . . .	14-61
POLYSWITCH PROTECTOR . . . . .	02-19
POP RIVETS & GUN . . . . .	14-12, 14-69
PORT SPEAKER TUBES . . . . .	06-43
PORTABLE . . . . .	
APPLIANCE TESTER . . . . .	10-12, 14-42
AUDIO AMPLIFIER . . . . .	06-22
HANDSFREE [MOBILE] . . . . .	17-02
PA SYSTEM . . . . .	06-26
SOLDERING . . . . .	14-25
SPEAKERS . . . . .	06-09
VIDEO MONITOR . . . . .	21-09
POTENTIOMETERS . . . . .	
CARBON . . . . .	02-15

FOCUS [TV] . . . . .	03-02
SWITCHPOTS . . . . .	03-02
TRIMMING . . . . .	02-15
WIRE WOUND . . . . .	02-15
POWER 240VAC . . . . .	
ADAPTORS . . . . .	12-22, 12-19
BOARDS . . . . .	12-04
CABLE . . . . .	13-12
CABLE CLAMPS . . . . .	12-18
CABLE GROMMETS . . . . .	12-15
CEILING ROSE . . . . .	12-14
CORDS . . . . .	12-12
DOUBLE ADAPTORS . . . . .	12-11
FINDER . . . . .	12-17
ISOLATION TRANSFORMER . . . . .	12-21
JUNCTION BOX . . . . .	12-17
LAMP BATTEN HOLDER . . . . .	12-14
LAMP CORD . . . . .	12-15
LAMPS . . . . .	02-20
LEADS . . . . .	12-12
LIGHT GLOBE DIMMER . . . . .	12-16
MAINS CORD . . . . .	12-15
MOUNT BLOCKS . . . . .	12-16
BRACKETS . . . . .	12-17
PACKS . . . . .	12-22
PLUGS & SOCKETS . . . . .	12-15
POINTS . . . . .	12-16
POWERWARE PROTECT . . . . .	12-04
RCD . . . . .	12-09
SAFETY PLUG . . . . .	12-15
SLIMLINE SURGE PROTECT . . . . .	12-09
SWITCH [APPLIANCE] . . . . .	02-28
SURGE PROTECTOR . . . . .	12-04
TIMER SWITCHES . . . . .	12-08
TRANSFORMERS . . . . .	12-20
UPS . . . . .	12-02
VARIAC . . . . .	12-21
POWER BOARD . . . . .	
CLEAN POWER . . . . .	12-04
COMPUTER . . . . .	12-04
INDIVIDUAL SWITCHED . . . . .	12-05
SAFETY SWITCH [RCD] . . . . .	12-09
SPACED SOCKETS . . . . .	12-05
STANDARD . . . . .	12-05
TIMER . . . . .	12-08
POWER PACKS . . . . .	12-22
DC PLUGS & LEADS . . . . .	07-20, 12-30
GAME CONSOLE [PS] . . . . .	15-11
GAME CONSOLE [PSP] . . . . .	15-06
GAMEBOY . . . . .	15-16
MULTI-VOLTAGE UNIVERSAL . . . . .	12-29
OTHER . . . . .	09-21, 15-18, 16-32, 17-03
POWER SUPPLY . . . . .	
13.8 VDC . . . . .	12-29
ANTENNA . . . . .	09-18, 09-21
COMPUTER . . . . .	16-41
GAMEBOY . . . . .	15-16
INLINE ANTENNA . . . . .	09-18, 09-21
ISOLATION . . . . .	03-05, 12-21
KINGRAY . . . . .	09-18
LAPTOP . . . . .	16-32
MOBILE PHONE CHARGE . . . . .	17-03
PACKS . . . . .	12-22
PANASONIC VCR KIT . . . . .	04-97
PLAYSTATION PS1/2X . . . . .	15-11
PLAYSTATION PSP . . . . .	15-06
SONY VCR . . . . .	04-97
TRANSFORMERS . . . . .	12-20
TRANSFORMERS [TV SMP]S . . . . .	03-03
UNINTERRUPTIBLE 12V . . . . .	12-35
UPS . . . . .	12-02
VARIABLE . . . . .	12-35
VCR . . . . .	04-97
XBOX . . . . .	15-14
POWER TOOL BATTERY . . . . .	11-62
POWERED SPEAKERS . . . . .	06-09
POWERED SPEAKERS . . . . .	06-25, 06-37
PRE PROGRAMMED REMOTES . . . . .	20-17
PREPARED LEADS . . . . .	08-02
PRINTER LEADS . . . . .	16-113
PROBE . . . . .	
HV . . . . .	03-08, 14-40
LOGIC . . . . .	14-48
OSCILLOSCOPE . . . . .	14-50
PULSE . . . . .	14-48
PROCESSOR VIDEO . . . . .	20-05
PROGRAMMABLE REMOTE . . . . .	20-18
PROTECTOR [SEE FUSES] . . . . .	02-23
PROTECTOR . . . . .	
MICROWAVE DIODE . . . . .	10-09
POWER SURGE [240VAC] . . . . .	12-04
TELEPHONE & FAX . . . . .	12-04, 12-09
THERMAL . . . . .	02-18
PROTOTYPE BOARDS . . . . .	01-17
PS3 CONTROLLER BATTERY . . . . .	11-49
PSP BATTERY . . . . .	11-49
PTC RESISTOR . . . . .	03-03
PUBLIC ADDRESS . . . . .	
AMPLIFIER . . . . .	06-22
HORN SPEAKER . . . . .	06-19, 06-47
SPEAKER . . . . .	06-12, 06-27
PUNCH DOWN TOOL . . . . .	14-13, 16-80
PVC . . . . .	
SAW . . . . .	14-14
TAPE . . . . .	14-58
TUNER . . . . .	02-03
PVR BACKUP BATTERY . . . . .	11-08, 11-18

## Q

QUARTZ HALOGEN LAMP . . . . .	12-11
QUICK DISCONNECT . . . . .	
GENERAL . . . . .	07-43
AUTOMOTIVE . . . . .	07-41, 18-52
KIT . . . . .	07-43, 18-34, 18-52
QUICK-BOND . . . . .	14-60
R . . . . .	
RABBIT EARS ANTENNA . . . . .	09-08
RACING CAR BATTERY . . . . .	11-20
RACK . . . . .	
AUDIO MIXER . . . . .	05-22, 06-24
MINI DISC . . . . .	05-21
MOUNT MODULATORS . . . . .	09-18
RJ45 PANEL . . . . .	16-102
RADIO ANTENNA . . . . .	
CAR TELESCOPIC . . . . .	18-59
CAR WINDOW . . . . .	18-68
CARAVAN & BOAT [FM] . . . . .	09-09
CB . . . . .	18-69, 19-20
FM . . . . .	09-08
MARINE . . . . .	19-20
MARINE AM/FM . . . . .	19-19
SCANNER . . . . .	18-69, 19-18
TELESCOPIC . . . . .	09-10
UHF . . . . .	18-69, 19-21
RADIO DIAL STRING . . . . .	05-06
RATCHET DRIVER . . . . .	14-04
RCA . . . . .	
LEADS . . . . .	08-01
PLUGS . . . . .	07-02, 07-14
SOCKETS . . . . .	07-03, 07-15
SWITCH BOX . . . . .	20-10
TERMINAL JOINER . . . . .	07-30
REAR PRO TV PARTS . . . . .	03-09
REAR VIEW CAMERA [CAR] . . . . .	18-22
RECHARGEABLE . . . . .	
BATTERY . . . . .	11-11
CORDLESS SCREWDRIVER . . . . .	14-03
DATA [CELL SIZE] . . . . .	11-09, 11-18
TORCHES . . . . .	12-36
RECORD CLEANER [VINYL] . . . . .	14-62
RECORD PLAYER . . . . .	
ACCESSORIES . . . . .	05-24
BELTS . . . . .	05-03
CARTRIDGE SCREWS . . . . .	05-24
CARTRIDGE WIRES . . . . .	05-24
CARTRIDGES . . . . .	05-23
HEAD SHELL . . . . .	05-24
INPUT CONVERTORS . . . . .	05-22
STYLUS . . . . .	05-25
STYLUS CLEANER . . . . .	14-62
RECORD & PLAYBACK HEADS . . . . .	
AUDIO CASSETTE . . . . .	05-04
VCR [A/C] . . . . .	04-09
VCR [VIDEO & HiFi] . . . . .	04-03
RECORD PLAY SWITCHES . . . . .	02-27
RECORDABLE MEDIA . . . . .	
8MM VIDEO CAMERA . . . . .	20-34
AUDIO CASSETTE . . . . .	20-35
BLUE RAY . . . . .	20-37
CD / CD-R / CD-RW . . . . .	20-38
DAT TAPES . . . . .	20-35
DVD / DVD±R / DVD±RW . . . . .	2





SUB WOOFER AMPLIFIER	06-37
SUB WOOFER TYMPHANY	06-100
SUB WOOFER X-OVER	06-40
SWITCH BOX	06-20
SYSTEMS	06-102
TAG STRIPS	06-42
TARGA	06-57
TERMINAL	06-41, 07-19
TILT BRACKET	06-39
TO RCA CONVERTER	06-40
TV	06-49
TWEETER - CTS	06-67
TWEETER - DAHCHI	06-52
TWEETER - FOUNTTEK	06-68
TWEETER - PAE	06-88
TWEETER - PEERLESS	06-90
TWEETER - SB	06-70
TWEETER - SCAN SPK	06-72
TWEETER - VIFA	06-82
USB DESKTOP	06-09
VIFA	06-82
VOLUME WALL PLATE	06-20
WALL	06-13
WALL MOUNT	06-13
WALL BRACKET	06-39, 20-39
WEATHER ENCLOSURE	06-46
WIRE & CABLE	13-10
WOOFER - CAR AUDIO	18-03
WOOFER - DAHCHI	06-55
WOOFER - LAT TYPE	06-100
WOOFER - PAE	06-89
WOOFER - PEERLESS	06-91
WOOFER - SB	06-70
WOOFER - SCAN SPEAK	06-78
WOOFER - TARGA	06-57
WOOFER - TYMPHANY	06-100
WOOFER - VIFA	06-84
SPIN MOTORS [CD/DVD]	05-08
SPINDLE [PLAYSTATION]	15-11
SPIRAL WIRE WRAP	13-15
SPIRIT LEVEL	14-20
SPLICING KIT [VCR TAPE]	04-100
SPLITTER	
ADSL	07-47, 16-97
ANTENNA	09-03
BNC ETHERNET	16-104
BOOSTED ANTENNA	09-02
CAR ACCESSORIES	17-04
COMPOSITE VIDEO	20-14
DVI	08-05, 16-66, 20-12
DVI CABLE	16-120
HDMI	16-67, 20-14
VGA	16-55, 20-14
VGA CABLE	16-117
YUV	20-14
SPRAYS	14-66
SPRING	
ANTENNA BASE	19-15
JVC VCR	04-48
PANASONIC	04-63
SHARP	04-72
SQUARE & LEVEL TOOL	14-20
STANDS	
DESK MIC	06-29
MICROPHONE	06-28
SPEAKER	06-38, 20-44
TRIPOD [SPEAKER]	06-27
TV	20-39
STARTER KIT PS2	15-08
STARTER KIT PSP	15-04
STARTER PACK [MOBILE]	17-02
STATIONS [SOLDERING]	
HAKKO	14-30
WELLER	14-26
STEERING WHEEL [XBOX]	15-13
STEP-DOWN TRANSFORMER	12-19
STEREO MODULATOR	09-13, 09-18
STEREO TO DIGITAL/OPTICAL	20-10
STICKY TAPE	14-58
STIFFENING CAPACITOR	18-30
STORAGE	
CD	05-21
DVD	16-28
TOOLS & COMPONENTS	14-18
STRAIN RELIEF BUSH	12-15, 13-15
STRIPPER [WIRE & CABLE]	14-13
STRIPS [LED LIGHT]	18-24
STRIPS [TERMINAL]	07-43
STROBE LIGHT [CAR]	18-25, 18-51
STROBES	21-28
STUD FINDER	14-17
STYLUS	05-25
STYLUS CLEANER	14-62
STYLUS - STANFIELD CAT	05-27
SUBWOOFER	
AMPLIFIER	06-37
CABINETS	18-08
CAR	06-50, 18-02
CROSSOVER	06-40
KIT	06-108
SPEAKERS [SEE SPEAKERS]	
SUPER BRIGHT LED	01-23
SUPER GLUE	14-61
SUPER LUBE	14-66
SUPPRESSOR [CAR NOISE]	18-30
SURFACE MOUNT DEVICE [SMD]	
5V REGULATOR	01-19
CAPACITOR	02-11
DESOLDER	14-30
REMOVAL KIT	14-37

REWORK STATION	14-33
SURGE PROTECTOR	
ARRESTER [GAS DC]	02-17
ARRESTER [LIGHTNING]	19-17
COMPUTER	16-36
MAINS POWER [240VAC]	12-09
POWERWARE PROTECT	12-02
TELEPHONE	07-46, 12-09
SURVEILLANCE [SEE SECURITY]	
SVGA [SEE VGA]	
S-VIDEO	
ADAPTORS	08-21
CABLE	13-04
CONVERTERS [VIDEO]	20-09
LEADS	08-21
PLUGS & SOCKETS	07-15
SWITCH BOXES	20-11
SVHS TAPES	20-34
SWABS & APPLICATORS	14-65
SWITCH	
ANTENNA [COMMS]	19-17
ANTENNA [TV]	09-02
APPLIANCE [TV ETC]	02-28
ATX COMPUTER POWER	16-41
AUTOMOTIVE	18-44
AUDIO/VIDEO	09-16, 15-19, 20-10
BUTTON	02-26
CARLING	02-31
CENTRE OFF	02-30
COMPUTER PERIPHERAL	16-51
COMPUTER POWER ATX	16-41
DASH BOARD	18-44
FOOT	02-27
GAME	15-19
GENERAL PURPOSE	02-30
ILLUMINATED	02-31
KEY	02-29
KICK	02-27
KNOB	02-32
KVM	16-51
LAMP	02-27
LEVER	02-27
MAINS POWER	12-16
MICRO	02-27
MICROWAVE	10-08
MOMENTARY	02-27
OPTICAL CABLE	08-02
PC	16-51
PEPI THERMAL	02-18
POWER [APPLIANCE]	02-28
POWER [MAINS]	12-16
PUSH	02-27
RECORD/PLAY	02-27
ROCKER	02-30
SAFETY [MAINS RCD]	12-09
SPEAKER SELECT	06-20
TACT	02-26
TAMPER	02-27, 21-28
THERMAL CUT	02-18
TIMER [MAINS]	12-08
TOGGLE	02-30
TV POWER	02-28
VCR	04-89
WALL PLATES	12-16
SWITCH BOX	
AV	09-16, 20-10
COMPUTER	16-51
KVM	16-51
SPEAKER	06-20
SWITCH MODE	
POWER UNIT [SONY VCR]	04-97
REPAIR KIT PANASONIC	04-97
REPAIR KIT [TV]	03-07
TRANSFORMER TV PWR	03-03
START UP PTC	03-03
SUPPLY [PLUG PACKS]	12-22
SYNTHETIC SOLDER	14-35
SYRINGE	
FLUX	14-37
GREASE	14-60
HEAT TRANSFER	14-61

## T

TACKLE BOX TRAYS	14-19
TACT SWITCHES	02-26
TAG STRIP	06-42
TAMIYA PLUGS	11-21
TAMPER	
LABELS	14-60
PAINT	14-60
SWITCH	21-27
TANTALUM CAPACITORS	02-05
TAPE	
ADAPTOR VHS-C	04-100
AUDIO	05-20, 20-35
BUTYL RUBBER	14-58
CAMCORDER	20-34
CASSETTE	05-20, 20-35
CD TO CASSETTE	05-21
CLEANERS [AUDIO]	05-20
CLEANERS [VCR]	04-100
DAT	05-20, 20-35
DOUBLE SIDED	14-59
DIGITAL AUDIO	05-20
DIGITAL VIDEO	20-34
DISPENSER	14-58
DOUBLE SIDED	14-59
DUCT	14-58
DV	20-34
ENDLESS	05-20
FOAM	14-59
GAFFER	14-58
GASKET	06-40
HEAD CLEAN	04-100, 05-20
HEADS [AUDIO]	05-04
HEADS [VCR]	04-03
INSULATION [PVC]	14-58
MASKING	14-58
MEASURE	14-20
MICRO-CASSETTE	05-20, 20-35
PACKING	14-58
PLAYER BELTS	05-02
PVC	14-58
SELF AMALGAMATING	14-58, 19-15
SPLICING [VHS & BETA]	04-100
STICKY	14-58
TEST [AUDIO]	05-19
TEST [VCR]	04-99
VHS & VHS-C	20-34
VIDEO	20-34
WINDERS	04-101
TAPWAVE ZODIAC BATTERY	11-49
TELEPHONE	
ADAPTOR	07-44, 16-98
ADSL ACCESS	07-46, 16-95
ANS MACHINE ADAPTOR	07-45
ANTENNA [PANASONIC]	09-09
CABLE	07-45, 13-12, 16-98
CORDLESS BATTERIES	11-22
CURLY CORDS	13-12
EXTENSION BELL	07-47
EXTENSION CABLE	07-44
EXTENSION REEL	07-44
GENDER CHANGES	07-45
HANDSET CORDS	07-45
LEADS	07-44, 16-98
MOBILE	17-02
MODULAR PRIVACY SW	07-45
MODE 3 ADAPTOR	07-44
MODEM ADAPTOR	07-46
MODULAR PLUG	07-45
MUSIC ON HOLD	07-46
PABX MUSIC	07-46
PLUGS	07-44
PRIVACY SWITCH	07-45
RINGERS	07-47
RJ11/RJ45 KIT	16-97
SHOULDER REST	07-46
SOCKET	07-44
SOLDERLESS TERMINLS	07-43
SURFACE MOUNT	07-46
SURGE PROTECTOR	07-46
SWITCH STOPPER	07-46
VOIP	16-96
WALL PLATE & SOCKET	07-46
TELESCOPIC ANTENNA	09-08, 09-10
TELEVISION [SEE TV]	
TELSTRA ANTENNA LEADS	17-28
TEMPERATURE	
MEASUREMENT PROBE	14-48
MULTI-METER	14-44
SENSORS	02-18
TEMPEST TV 12V PSU BLK	03-07
TENSION BAND [VCR]	04-85
ADHESIVE PAD	04-97
TERMINAL	
BATTERY SNAP [9V]	11-70
BLOCKS	07-42, 12-18
CAR BATTERY	18-42
JOINER & SPLICER	07-42
RING & SPADE	07-05, 07-18, 07-43
SPEAKER	07-19
STRIP	07-43, 12-18
WAGO	07-42
TERMINATOR	
BNC	07-22
END CAPS	07-37
F PLUG	07-24

SCREW	07-43
SCSI	16-110
TEST	
CASSETTE [AUDIO]	05-19
CASSETTE [VHS VCR]	04-99
CD	05-19
CD [OFFICIAL]	18-39
CLEAR VHS CASSETTE	04-99
EQUIPMENT	14-39
LEADS	14-50
PATTERN GENERATE	14-39, 16-76
SCREWDRIVER [AC]	14-48
VHS VCR ALIGNMENT	04-99
TESTER	
APPLIANCE	10-12, 14-42
ANTENNA VSWR	14-41, 19-17
BATTERY	11-08
COMPUTER ATX POWER	16-81
CRT	14-40
EHT TRANSFORMER	03-06
EMF	14-48
ETHERNET CABLE	16-81
LOPT	03-06, 14-40
MICROWAVE	10-07, 14-48
REMOTE CONTROL	20-18
RJ45 & BNC NET CABLE	16-81
TFT LCD MONITORS	21-09
THERMAL	
BREAKER	02-18, 10-12, 12-16
CUTOFF	02-18, 02-24
FUSE	02-24
SENSOR	02-18, 10-12
SWITCH	02-18
TRANSFER COMPOUND	01-16
THERMISTOR	02-18
THERMISTOR [MWO]	10-12
THERMOMETER	12-10, 14-48
THYRISTORS	01-21
TIES [CABLE]	13-17
TIES GUN	13-17, 14-12
TIME CLOCK [TRAVEL]	12-10
TIMERS [240VAC]	12-08, 21-27
TIP SUIT SOLDERING IRONS	14-24
TNC	
ADAPTORS	07-35
PLUGS & SOCKETS	07-26
TOGGLE SWITCHES	02-30
TOOL	
1/4 HEX	14-03
ADJUSTABLE WRENCH	14-17
AIR COMPRESSOR	18-51
ALIGNMENT DRIVER	14-07
ALLEN KEYS	14-08
ANTENNA WRENCH [CAR]	18-50
BOX	14-19
BRUSHES [CLEANING]	14-64
BRUSHES [PAINT]	14-17
CABLE PULLER	14-17
CABLE STRIPPER	14-13
CABLE TIE GUN	14-12
CAR RADIO SERVICE	18-50
CASE	14-19
CERAMIC DRIVER	14-07
CLAMP SEIZER	14-17
COAX STRIPPER	14-13
COMBINATION SET	14-07
COMPUTER ETHERNET	16-80
COMPUTER POWER	16-81
CONDUIT CUTTER	14-15
CRIMPING	14-10
CUTTER	14-13
DEGAUSSING WAND	14-40
DESOLDERING	14-38
DRILL BITS	14-70
ETHERNET	16-80
FINDER	14-17
FLAT BLADE DRIVERS	14-02
FUSE REMOVER	14-08
GLOVES	14-57
GLUE GUN & STICKS	14-24
HACK SAW	14-14
HANDY TOOL KIT	18-50
HELPING HANDS	14-23
HERBIE CLIP	13-16
HEX KEYS	14-08
HEX TIPS	14-05
HIGH VOLTAGE PROBE	14-40
HOLE SAW	14-18
IC REMOVER	14-09
IDC PUNCH DOWN	14-13, 16-80
IMPACT WRENCH [12V]	18-51
INSULATED DRIVERS	14-02
KNIFE	14-13
LAN	16-81
LONG NOSE	14-16
MAGNIFIER	14-22
MIRROR	14-22
MOBILE PHONE	17-39
MODULAR CRIMP	14-12
NEEDLE FILE	14-08
PEARL CATCHER	14-09
PHILIPS SCREWDRIVER	14-02
PLCC EXTRACTOR	14-09
POP RIVET GUN	14-12
RATCHET	14-04
REMOTE CONTROL TEST	20-18
SCISSOR CLAMP	14-17
SCRIBER	14-17
SIDE CUTTER	14-14
SOCKET & WRENCH	14-09



SPIRIT LEVEL . . . . .	14-20	GAUGES . . . . .	05-24	TUNERS [PCI & PCIe & USB].	16-49
STUD FINDER . . . . .	14-17	MOTOR . . . . .	05-06	VARIATOR [SHARP].	03-03
TAPE MEASURE . . . . .	14-20	STYLUS . . . . .	05-25	WALL BRACKETS . . . . .	20-39
TEST SCREWDRIVER . . . . .	14-48			WALL PLATE [ANTENNA].	09-02
TORCH . . . . .	14-22, 12-36, 18-23	TV		YOKES . . . . .	03-04
TORX & TRI-WING . . . . .	14-05	2.4 & 5.8GHZ SENDER . . . . .	20-30	TWEETER . . . . .	
TWEEZERS . . . . .	14-21	300 OHM RIBBON CABLE . . . . .	13-07	CTS . . . . .	06-67
VCR SERVICE . . . . .	04-98	75 OHM CABLE . . . . .	13-06	DAI-ICHI . . . . .	06-52
VIDEO HEAD EXTRACT . . . . .	14-09	75 OHM LEADS . . . . .	08-25	FOUNTEK RIBBON . . . . .	06-68
VESSEL . . . . .	14-02	75 OHM SOCKET / SPLIT . . . . .	09-02	HORN . . . . .	06-67
WALLET . . . . .	14-09	75 OHM TUNER . . . . .	03-02	PAE . . . . .	06-88
WIRE STRIPPER . . . . .	14-13	ALIGNMENT TOOL . . . . .	14-07	PEERLESS . . . . .	06-90
TORCH		AMP MASTHEAD . . . . .	09-19	PIEZO HORN . . . . .	06-52
BATTERY . . . . .	11-02	AMP SPLITTER . . . . .	09-02	SB ACOUSTICS . . . . .	06-70
BICYCLE . . . . .	12-37	ANALOGUE TUNER ADAPT . . . . .	09-15	SCAN SPEAK . . . . .	06-72
BLOW, MINI . . . . .	14-24	ANTENNA BOOSTER . . . . .	09-02	VIFA . . . . .	06-81
DIVING / SCUBA . . . . .	12-36	ANTENNA BOOST [GME].	09-18	TWEEZERS . . . . .	14-21
GLOBES . . . . .	02-20	ANTENNA INDOOR . . . . .	09-08	TWO WAY RADIO BATTERY . . . . .	11-58
LED . . . . .	12-36	ANTENNA LEADS . . . . .	08-25	TYRES [IDLER].	
MINERS . . . . .	12-37	ANTENNA LEAD [HQ].	08-12	AUDIO . . . . .	05-05
TOOL . . . . .	14-08	ANTENNA ROTATOR . . . . .	09-15	VCR . . . . .	04-25
TOROIDAL TRANSFORMER . . . . .	12-21	ANTENNA SWITCH . . . . .	09-02		
TORX . . . . .	14-05	ANTENNA TELESCOPIC . . . . .	09-10		
TOSLINK ADAPTORS & LEADS . . . . .	08-02	ATTENUATORS 75 OHM . . . . .	09-03		
TOWER SPEAKERS . . . . .	06-104	ATTENUATORS "F" . . . . .	09-05		
TOWERS MANUAL . . . . .	14-54	AV LEADS . . . . .	08-10, 08-14		
TOY CAR BATTERIES . . . . .	11-20	AV MODULATOR . . . . .	09-13, 20-32		
TRANSFORMER		AV SENDER . . . . .	09-12, 20-30		
240VAC TO 115VAC . . . . .	12-19	AV SWITCH . . . . .	09-16, 20-10		
AC INTERNAL C-CORE . . . . .	12-20	AV TO RF CONVERTER . . . . .	09-13		
AC POWER PACKS . . . . .	12-24	BALUN INLINE . . . . .	09-02		
BALUN LINE [AUDIO].	07-06	BALUN MASTHEAD . . . . .	09-03		
BALUN [TV].	07-31	BAND SEPARATOR . . . . .	09-02		
DC POWER PACKS . . . . .	12-22	BOOSTED SPLITTER . . . . .	09-02		
EHT . . . . .	03-10	BOOSTERS . . . . .	09-15		
FENDER . . . . .	01-28	BRACKETS & STANDS . . . . .	20-39		
FUSES . . . . .	02-24	CABLE [ANTENNA].	13-06		
HIGH VOLTAGE [TV].	03-10	CABLE [AV].	13-04		
INVERTER . . . . .	12-33	COMPUTER CARD . . . . .	16-49		
ISOLATION . . . . .	12-21	COMPUTER CONVERT . . . . .	16-72		
LINE [100V].	06-19	CRT SOCKETS . . . . .	03-04		
LOPT . . . . .	03-10	DEFLECTION YOKES . . . . .	03-04		
MARSHAL . . . . .	01-28	DEGAUSSING WAND [CRT].	03-05		
MICROWAVE . . . . .	10-06	DIPLEXER . . . . .	09-03, 09-21		
MONITOR LOPT . . . . .	03-17	DISTRIBUTION AMP TV . . . . .	09-18		
MULTI-VOLTAGE . . . . .	12-29	DISTRIBUTION VIDEO . . . . .	09-17, 20-14		
PLUG PACK . . . . .	12-22	DVD TO TV RF ADAPTOR . . . . .	09-13		
STEP DOWN 240-115V . . . . .	12-19	ENTRY BOX [TV ANT].	09-02		
SWITCH MODE [TV].	03-03	F ATTENUATOR . . . . .	09-05		
TOROIDAL . . . . .	12-21	F ENTRY . . . . .	09-04		
UPS-12VDC . . . . .	12-35	F SPLITTER . . . . .	09-04		
UPS-240VAC . . . . .	12-02	F TERM 75 OHM . . . . .	09-05		
VARIAC . . . . .	12-21	F WALL PLATE . . . . .	09-04		
TRANSIENT SUPPRESSOR . . . . .	02-19	FM FILTER . . . . .	09-22		
TRANSISTOR . . . . .	01-02	FM INDOOR ANT . . . . .	09-08		
MOUNTING . . . . .	01-18	FM SPLITTER . . . . .	09-03		
PHOTO . . . . .	01-22, 01-24	FLYLEADS . . . . .	08-25		
SELECTOR . . . . .	01-15, 01-17	FOCUS POTS & RESISTORS . . . . .	03-02		
TRANSMITTER		FORMAT CONVERTER . . . . .	20-06		
AV ETC. VIA CAT5 . . . . .	20-24	GAME ANT SWITCH . . . . .	09-02		
BLUETOOTH . . . . .	16-87, 17-08	GAME ANT SWITCH . . . . .	15-18		
IR DIODE MODULES . . . . .	20-23	GAME AV SELECT . . . . .	15-19		
KVM . . . . .	16-51	GYPROCK MOUNT . . . . .	09-05		
SECURITY CAMERA . . . . .	21-08	IKON MANUAL . . . . .	14-55		
TRANSPARENT VHS TEST . . . . .	04-99	INDOOR ANT . . . . .	09-08		
TRAP_CERAMIC . . . . .	02-16	JACKS . . . . .	07-24		
TRAVEL		KINGRAY . . . . .	09-18		
ADAPTORS . . . . .	12-19	LINEARITY COIL . . . . .	03-03		
CHARGER [CELL PHONE].	17-03	MANUALS . . . . .	14-55		
CLOCK . . . . .	12-10	MASTHEAD AMP . . . . .	09-19		
TRAY [MICROWAVE OVEN]		MASTHEAD BALUN . . . . .	09-02		
CARRIER . . . . .	10-12	MATCHING BALUN . . . . .	09-02		
COUPLER . . . . .	10-12	MINI TV ADAPTOR . . . . .	09-02		
GLASS . . . . .	10-12	MOD KITS . . . . .	03-07		
TRAYS [COMPONENT].	14-69	MODULATORS . . . . .	09-13		
TRIACS . . . . .	01-21	MOUNTING . . . . .	20-39		
TRI-COLOUR LED . . . . .	01-22	NTSC TO PAL . . . . .	20-08		
TRIMMER CAPACITORS . . . . .	02-03	PAL FORMAT CONVERT . . . . .	20-08		
TRIMMER POTS . . . . .	02-15	PAL ENTRY BOX [ANT].	09-02		
TRIP POWER BOARDS . . . . .	12-04	PAL SPLITTER [ANT].	09-02		
TRIPLERS [TV].	03-06	PAL TO NTSC . . . . .	20-08		
TRIPOD[MICROPHONE].	06-28	PATTERN GENERATOR . . . . .	03-05		
TRIPOD[SPEAKER].	06-27	PLUGS [ANTENNA].	07-23		
TRI-WING SCREWDRIVER . . . . .	14-06	PLUGS [AV].	07-02		
TUBE		PTC . . . . .	03-03		
CRT SOCKET . . . . .	03-04	REMOTE CONTROLS . . . . .	20-18		
DEGAUSSING . . . . .	14-40	REMOTE CONT EXTEND . . . . .	09-12		
REJUVENATOR . . . . .	14-40	REMOTE CONT EXTEND . . . . .	20-30		
VALVE SOCKET . . . . .	01-28	REMOTE CONT REPEATER . . . . .	20-23		
VALVES . . . . .	01-25	RF ADAPTOR DVD . . . . .	09-13		
TUBING HEAT SHRINK . . . . .	13-18	SATELLITE LINE AMP . . . . .	09-04		
TUNER		SATELLITE SPLITTER . . . . .	09-04		
AM-FM RADIO . . . . .	02-03	SCART LEADS . . . . .	08-10, 08-13		
EXTERNAL TV . . . . .	09-15	SET TOP BOX . . . . .	20-02		
MULTI-SYSTEM . . . . .	20-05	SET TOP RECORDER . . . . .	20-03		
PCI & PCIe CARD . . . . .	16-48	SIGNAL EXPLORER . . . . .	14-41		
SET TOP BOX . . . . .	20-18	SOCKETS [ANTENNA].	07-23		
STAND ALONE . . . . .	20-04	SOCKETS [AV].	07-02		
TV FOR MONITOR . . . . .	09-15, 20-04	SPEAKER . . . . .	06-49		
TV . . . . .	03-02	SPLITTER . . . . .	09-02		
UHF-VHF UNIVERSAL . . . . .	03-02	SPLITTER BOOST [ANT].	09-02		
TUNING		SPLITTER BOOST [AV].	09-17		
BLOCKS [VR].	03-04	SUPPORTS & STANDS . . . . .	20-39		
CAPS . . . . .	02-03	STEREO MODULATORS . . . . .	09-18		
GANG . . . . .	02-03	SWITCHMODE TX . . . . .	03-03		
TRACKS [PHILIPS].	03-02	SYSTEM CONVERTERS . . . . .	20-08		
TURNTABLE		TELESCOPIC ANTENNA . . . . .	09-10		
ACCESSORIES . . . . .	05-24	TEST INSTRUMENTS . . . . .	03-05		
BELT . . . . .	05-03	TUNING BLOCKS . . . . .	03-04		
CARTRIDGES . . . . .	05-23	TUNERS [SPARE PARTS].	03-02		
		TUNERS [STAND ALONE].	20-04		

## V

VALVE AMPLIFIER . . . . .	06-112
VALVES . . . . .	01-25
CAPACITORS . . . . .	01-29
LISTING . . . . .	01-29
OUTPUT TRANSFORMER . . . . .	01-28
SOCKETS . . . . .	01-28
VARIABLE POWER SUPPLY . . . . .	12-35
VARIABLE RESISTOR . . . . .	02-15
VARIAC . . . . .	03-05, 12-21, 14-40
VARIATOR . . . . .	02-19, 03-03
VARIATOR [MICROWAVE].	10-12
VARTA [SEE BATTERY].	11-11, 11-18
VCR [ACCESSORIES & PARTS]	
ALIGN TAPES . . . . .	04-99
ALIGN TOOLS . . . . .	04-99, 14-07
ARM . . . . .	04-34
AV LEADS . . . . .	08-14
AV SENDER . . . . .	20-30
BATTERY BACK UP . . . . .	11-07, 11-18
BELT . . . . .	04-24, 05-02
BELT KIT . . . . .	04-21
BRAKE LEVERS . . . . .	04-34
BRAKE PAD . . . . .	04-97
CABLE [AV].	13-04
CAMCORDER BATTERY . . . . .	11-32
CASSETTE HOUSING . . . . .	04-82
CASSETTE REPAIR . . . . .	04-100
CASSETTE TAPE . . . . .	20-34
CLEANER TAPE . . . . .	20-34
CLEANER ROLLER . . . . .	04-39 to 79
CLUTCH . . . . .	04-25
CRYSTAL . . . . .	02-16, 04-97
DUBBING LEADS . . . . .	08-24
FAULT MANUAL . . . . .	04-101, 14-55
FORMAT CONVERTER . . . . .	20-06
FRONT LOADER . . . . .	04-82
GEAR . . . . .	04-34
GEAR KIT [JVC].	04-31
GEAR KIT [LG].	04-43
GEAR KIT [PANASONIC].	04-24/32
GREASE . . . . .	04-97, 14-61
GUIDE POST . . . . .	04-39
HEAD [A/C].	04-09
HEAD [VIDEO].	04-03
HAND TOOL . . . . .	04-98
HEAD CLEANER . . . . .	04-100
HEAD EXTRACTOR . . . . .	04-98
IDLER ASSEMBLIES . . . . .	04-34
IDLER TYRES . . . . .	04-25
IR RECEIVER DIODES . . . . .	04-96
LAMPS . . . . .	04-96
LEADS . . . . .	08-14, 08-16
LED [SENSOR].	04-96
LEVERS . . . . .	04-35
LOAD DRIVE MECH . . . . .	04-45
MIXER . . . . .	20-05
MODE SWITCHES . . . . .	04-89
MODULATOR . . . . .	20-32
MOTORS . . . . .	04-10
OPTO COUPLERS . . . . .	04-96
OVERHAUL KITS . . . . .	04-31
PHOTO DIODE . . . . .	04-96
PINCH ROLLER . . . . .	04-26
PINCH ROLLER ARMS . . . . .	04-28
PORTABLE MONITORS . . . . .	21-09
POWER SUPPLY REPAIR . . . . .	04-97
POWER SUPPLY [SAM].	04-68
POWER SUPPLY [SONY].	04-80
REEL DRIVE . . . . .	04-34, 04-55, 04-79
REEL SENSOR . . . . .	04-96
REMOTE CONTROLS . . . . .	20-16
REPAIR KITS . . . . .	04-31, 04-81, 04-97
REWINDER . . . . .	04-101
RF [DAEWOO].	04-38
RF [SAMSUNG].	04-67
RF ADAPTOR . . . . .	20-32
ROTATION SENSOR . . . . .	04-96
SCALERS . . . . .	20-13
SECURITY LABELS . . . . .	04-99
SENDER . . . . .	20-30
SENSOR LAMP / LED . . . . .	04-96
SERVICE TOOLS . . . . .	04-98, 14-02
SIDE PLATE . . . . .	04-62, 04-82
SPLICE KIT [TAPE].	04-100
STABILIZER [VIDEO].	09-15
SWITCHES . . . . .	04-89
SWITCHES [TACT].	02-26
SWITCHING BOXES . . . . .	20-10
TAMPER LABELS . . . . .	04-99
TAPE COVERS [VHS].	20-34
TAPE REPAIR [SPLICE].	04-100
TAPES . . . . .	20-34
TENSION BANDS . . . . .	04-85
TEST CASSETTE . . . . .	04-99
TEST TAPES . . . . .	04-99
TOOLS . . . . .	04-98
TRANSMITTER . . . . .	20-30
TEST CASSETTE . . . . .	04-99
TYRES . . . . .	04-25
UPPER DRUM . . . . .	04-03
VGA CONVERTER . . . . .	20-06
VIDEO CORRECT . . . . .	20-05
VIDEO HEAD EXTRACT . . . . .	04-98
VIDEO STABILIZER . . . . .	09-15, 20-05
VELCRO STRAP . . . . .	13-14, 18-47



Video Signal Convertors, Scalers  
& Distribution Systems  
See Section 16 & 20



CYPRESS TECHNOLOGY CO., LTD  
www.cypress.com.tw

**omb**  
MADE IN ITALY

Audio Visual Support Solutions

See Section 20 for OMB  
Visit Online: [www.ombitaly.it](http://www.ombitaly.it)  
[www.wecomponents.com/omb](http://www.wecomponents.com/omb)

SUPERIOR SOUND QUALITY  
AND PERFORMANCE



**AV-LINK**  
HDMI™  
HIGH DEFINITION MULTIMEDIA INTERFACE

CERTIFIED HDMI CABLES FOR MAXIMUM  
SIGNAL CLARITY & HDTV ACCURACY  
SEE SECTION-08 & SECTION-20

GAME CONSOLES & COMPUTERS    AV RECEIVERS    DVD PLAYERS & DIGITAL SET-TOP BOXES    VIDEO DISPLAYS

EXTENSIVE RANGE OF CELLULAR,  
WIRELESS DATA, NAVIGATION  
& MEDIA ACCESSORIES.

Section 17 Cellink - Visit Online: [www.cellink.com.au](http://www.cellink.com.au)

**Cellink**  
Mobile Media Products

**daichi**<sup>®</sup>

New Range:  
*Super Resolution*

See Section 6 for our  
full range of drivers...

**COBY**<sup>®</sup>

SUPERNAMIC  
HEADPHONES

Visit Online: [www.coby.com.au](http://www.coby.com.au)  
See Section 6 for Coby Headphones

**ceramica**

300,000 Hours Of Fan Life  
Low Noise & High Reliability

Available from 25mm to 120mm  
in 5V, 12V, 24V, 48V models

Section 16 for Ceramic Bearing Fans  
Visit Online: [www.ceramicfans.com](http://www.ceramicfans.com)



# Wagner

[www.wagner.net.au](http://www.wagner.net.au)

More Products Available  
See Sections 01 to 10

**Wagner**  
ELECTRONIC SERVICES A/Asia  
138 LIVERPOOL RD ASHFIELD 2131  
PH 02 97989233 FAX 02 97980017

September 2009 Australia

SEMICONDUCTORS	01	12
ELECTRONIC COMPONENTS	02	13
TELEVISION COMPONENTS	03	14
VIDEO CASSETTE COMPONENTS	04	15
AUDIO CD DVD & PHOTO	05	16
SPEAKERS	06	17
PLUGS & SOCKETS	07	18
PREPARED LEADS	08	19
ANTENNA ACCESSORIES	09	20
MICROWAVE COMPONENTS	10	21
INTERNALS	11	FOR SECTIONS 12 TO 21 SEE CATALOGUE "A"

**25 YEARS** CELEBRATING 25 YEARS OF THE FUTURE PRODUCT

Phone: 02 9798-9233  
Fax: 02 9798-0017  
Email: [sales@wagner.net.au](mailto:sales@wagner.net.au)  
Web: [www.wagner.net.au](http://www.wagner.net.au)

**PART 1 of 2**

**Wagner**  
ELECTRONIC SERVICES A/Asia  
138 LIVERPOOL RD ASHFIELD 2131  
PH 02 97989233 FAX 02 97980017

September 2009 Australia

SEMICONDUCTORS	01	12
ELECTRONIC COMPONENTS	02	13
TELEVISION COMPONENTS	03	14
VIDEO CASSETTE COMPONENTS	04	15
AUDIO CD DVD & PHOTO	05	16
SPEAKERS	06	17
PLUGS & SOCKETS	07	18
PREPARED LEADS	08	19
ANTENNA ACCESSORIES	09	20
MICROWAVE COMPONENTS	10	21
INTERNALS	11	FOR SECTIONS 12 TO 21 SEE CATALOGUE "A"

**25 YEARS** CELEBRATING 25 YEARS OF THE FUTURE PRODUCT

Phone: 02 9798-9233  
Fax: 02 9798-0017  
Email: [sales@wagner.net.au](mailto:sales@wagner.net.au)  
Web: [www.wagner.net.au](http://www.wagner.net.au)

**PART 2 of 2**

For Sections 01 to 10  
See Catalogue "A".....

# Wagner

**ELECTRONIC SERVICES A/Asia**  
**138 LIVERPOOL RD ASHFIELD 2131**  
**PH 02 97989233 FAX 02 97980017**

**WAGNER ELECTRONICS PROUDLY DISTRIBUTING:**



Cellink cellular communications Accessories.  
 High Quality products and attractively packaged for retail display. Extensive range of accessories includes Batteries, Chargers, RF Accessories, Cases & Much More...  
[www.cellink.com.au](http://www.cellink.com.au)



LCD / PLASMA and Audio Visual mounting solutions from OMB are designed and built in Italy. Supports are extremely well designed using quality materials & robust construction for extra long reliability. Mounting solutions for all types of Audio Visual equipment.  
[www.ombitaly.it](http://www.ombitaly.it)



Cypress Technology designs and manufactures high end audio visual distribution systems and signal format conversion devices. No matter how large or small the installation Cypress products have an audio / visual solution for your needs.  
[www.cypress.com.tw](http://www.cypress.com.tw)



Ceramica Cooling fans are unlike any other fan. The Ceramica fans have ceramic components in the fan that increase running time dramatically and is unmatched by traditional ball-bearing or sleeve fan comparisons. Available with PWM, and in Various Sizes and Speeds.  
[www.ceramicafans.com](http://www.ceramicafans.com)



Dai-ichi has a long history of high performance Hi-Fi speaker driver design & manufacturing. The choice of professionals for the exceptional sound reproduction and value. Range includes precision sounding tweeters, dynamic mid-woofer & sub-woofer drivers. Dai-chi also carries an extensive range of electronic accessories & parts.



Accento Dynamica specialises in multi-room audio speakers for domestic and commercial applications. Accento speakers are all about giving people the best possible listening experience whether it be in the school hall or in your home HiFi. High quality construction and sound quality you can rely on.



Europe's finest brand in speaker drivers Peerless & ScanSpeak are renowned for there innovation, reliability, performance and many industry firsts. These speaker drivers are the choice for many of the worlds largest speaker system manufactures due to there outstanding characteristics  
[www.tymphany.com](http://www.tymphany.com) [www.scan-speak.com](http://www.scan-speak.com)



Coby Electronics is a leading manufacturer for high quality audio headphones that give dynamic sound and modern styling. Coby headphones are available in number different types including overhead, in-ear, street style behind neck, wireless and more.



**PLEASE NOTE :** The entire contents of this catalogue, including illustrations, code numbers, information and page formats are subject to copyright. Reproduction or transmission in any form is prohibited by law. Logos, etc. are covered by each registered companies copyrights. Due to the dynamic nature of this industry, products descriptions, although correct at the time of printing, are subject to change without notice.



**Phone:** 02 9798-9233  
**Fax:** 02 9798-0017  
**Email:** [sales@wagner.net.au](mailto:sales@wagner.net.au)  
**Web:** [www.wagner.net.au](http://www.wagner.net.au)